

FTB-5240S/S-P

Optical Spectrum Analyzer for FTB-200 v2



Copyright © 2009–2013 EXFO Inc. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, be it electronically, mechanically, or by any other means such as photocopying, recording or otherwise, without the prior written permission of EXFO Inc. (EXFO).

Information provided by EXFO is believed to be accurate and reliable. However, no responsibility is assumed by EXFO for its use nor for any infringements of patents or other rights of third parties that may result from its use. No license is granted by implication or otherwise under any patent rights of EXFO.

EXFO's Commerce And Government Entities (CAGE) code under the North Atlantic Treaty Organization (NATO) is 0L8C3.

The information contained in this publication is subject to change without notice.

Trademarks

EXFO's trademarks have been identified as such. However, the presence or absence of such identification does not affect the legal status of any trademark.

Units of Measurement

Units of measurement in this publication conform to SI standards and practices.

Patents

Feature(s) of this product is/are protected by one or more of US patents 6,636,306; 8,358,930; 8,364,034 and equivalent patents pending and granted in other countries; patent appl. US 2013/0163987 A1; and US patents 6,612,750 and 8,373,852.

Version number:10.0.3

Contents

Certification Information	vi
1 Introducing the FTB-5240S/S-P Optical Spectrum Analyzer	1
Models	2
Typical Applications	3
Optional Software Packages	4
Post-Processing Application	5
Conventions	6
2 Safety Information	7
3 Getting Started with Your OSA	9
Inserting and Removing Test Modules	9
Starting Module Applications	15
4 Preparing Your OSA for a Test	17
Cleaning and Connecting Optical Fibers	17
Installing the EXFO Universal Interface (EUI)	19
Selecting a Test Mode	20
Switching Modes While a Trace is Open	22
Nulling Electrical Offsets	23
Performing User Calibration	25
Using the Autonaming Feature	37
5 Setting Up the Instrument in WDM Mode	41
Defining Preferences	43
Setting Up WDM Analysis Parameters	59
Setting Up Acquisition Parameters	86
6 Setting Up the Instrument in Drift Mode	91
Defining Preferences	93
Setting Up Drift Analysis Parameters	107
Setting Up Acquisition Parameters	131
Building a Custom Drift Measurement	138
7 Setting Up the Instrument in DFB Mode	149
Defining Preferences	150
Setting Up Acquisition Parameters	160

8	Setting Up the Instrument in FP Mode	163
	Defining Preferences	164
	Setting Up Acquisition Parameters	173
9	Setting Up the Instrument in Spectral Transmittance Mode	177
	Defining Preferences	178
	Setting Up Spectral Transmittance Analysis Parameters	187
	Setting Up Acquisition Parameters	195
10	Setting Up the Instrument in EDFA Mode	199
	Defining Preferences	201
	Setting Up EDFA Analysis Parameters	215
	Setting Up Acquisition Parameters	232
11	Starting a Measurement	237
12	Managing Files and Test Configurations	239
	Using the Discover Feature	239
	Managing Measurement Files	242
	Opening Files in Other Test Modes	246
	Managing Favorites	250
	Importing a Configuration from the Current Trace	260
	Using a Restore Point	260
13	Managing Results	261
	Managing WDM Test Results	262
	Managing Drift Test Results	276
	Managing DFB Test Results	287
	Managing FP Test Results	291
	Managing Spectral Transmittance Test Results	295
	Managing EDFA Test Results	300
	Adjusting the Display Size	306
	Viewing WDM Graph in Full-Screen Mode	308
	Using Zoom Controls	309
	Managing Markers	311
	Managing Trace Information	315
	Generating Reports	319
14	Maintenance	321
	Cleaning EUI Connectors	321
	Recalibrating the Unit	324
	Recycling and Disposal (Applies to European Union Only)	325

15 Troubleshooting	327
Viewing Online Documentation	327
Contacting the Technical Support Group	328
Transportation	330
16 Warranty	333
General Information	333
Liability	334
Exclusions	335
Certification	335
Service and Repairs	336
EXFO Service Centers Worldwide	337
A Technical Specifications	339
B Formulas Used with Your Optical Spectrum Analyzer	341
EDFA Noise Figure Calculation	341
Central Wavelength Calculation (Spectral Transmittance)	342
Bandwidth Calculation (Spectral Transmittance)	343
Index	345

Certification Information

North America Regulatory Statement

This unit was certified by an agency approved in both Canada and the United States of America. It has been evaluated according to applicable North American approved standards for product safety for use in Canada and the United States.

Electronic test and measurement equipment is exempt from FCC part 15, subpart B compliance in the United States of America and from ICES-003 compliance in Canada. However, EXFO Inc. makes reasonable efforts to ensure compliance to the applicable standards.

The limits set by these standards are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the user guide, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.


European Community Declaration of Conformity

An electronic version of the declaration of conformity for your product is available on our website at www.exfo.com. Refer to the product's page on the Web site for details.

1 **Introducing the FTB-5240S/S-P Optical Spectrum Analyzer**

The FTB-5240S/S-P Optical Spectrum Analyzer (OSA) is designed to measure optical power as a function of wavelength or frequency and Optical Signal to Noise Ratio (OSNR).

Your OSA offers truly portable spectral characterization for DWDM network commissioning, as well as InBand Optical Signal to Noise Ratio (OSNR) measurement for ROADM and 40 Gbit/s signals and networks.



Models

The OSA comes in different models:

- FTB-5240S: The FTB-5240S is a small form factor expert DWDM OSA designed for efficient commissioning, maintenance and troubleshooting of DWDM components and links in the field, from 25 GHz to CWDM. It can measure power as a function of wavelength for new modulation schemes, such as non-return-to-zero (NRZ), duo binary, which present large line widths and often display multiple peaks. In-depth analysis ensures the correct identification and signal measurement of each carrier. It also measures OSNR based on the IEC 61280-2-9 method.
- FTB-5240S-P: It is the FTB-5240S model with a polarization controller. It is a hardware-ready version of an expert OSA (two-slot unit), without the software to compute the InBand/*i*-InBand OSNR. You can upgrade this model on field using the software key, and it will become fully capable of InBand/*i*-InBand OSNR measurement.
- FTB-5240S-P-InB: It is the FTB-5240 S-P model (two-slot unit) with the software to compute the InBand/*i*-InBand OSNR. This software allows you to make either IEC-Based OSNR measurements, or In-Band OSNR measurements, required when the inter-channel noise is not representative of the noise under the signal peaks or when crosstalk is dominant.
- High Power Model (HPW): This model allows you to connect the FTB-5240S or FTB-5240S-P OSA to a network that carries very high optical power. This situation becomes more common with the deployment of latest CATV networks. The sensitivity of this OSA model is shifted accordingly and the module is protected to work under these extended power levels.

Typical Applications

You can use your OSA for the following tasks:

- Characterizing channels in the O- to U-band spectra
- Testing laser sources for spectral purity and power distribution
- Testing the transmission characteristics of optical devices
- Troubleshooting and monitoring key parameters on CWDM or DWDM signals to check system stability
- Characterizing all channel spacings, from 50 GHz DWDM to CWDM
- Testing high-speed networks (beyond 40 Gbit/s)
- Measuring OSNR, but specifically within the channel (InBand OSNR) for FTB-5240S-P-InB model

Optional Software Packages

Optional software options are available for your application.

Option Name	Description
Advanced (Adv)	<p>The Advanced option gives you access to the following test modes:</p> <ul style="list-style-type: none">▶ Drift: time-based WDM analysis for signal monitoring.▶ ST: characterization of the spectral transmittance of optical components such as filters.▶ EDFA: characterization of the performance of an Erbium Doped Fiber Amplifier.▶ DFB: characterization of a DFB laser source.▶ FP: characterization of a Fabry-Perot laser source.
In-Band (InB)	<p>The In-Band option enables you to perform In-Band noise analysis for WDM and WDM drift measurements.</p> <p style="text-align: center;">Note: <i>Not supported by the FTB-5240S module.</i></p> <p>When this option is activated, it is possible to have access to user-defined acquisition and analysis parameters for custom In-Band noise measurement (WDM and WDM drift modes)</p>

Option Name	Description
WDM Investigator (Inv)	<p>This option activates the WDM Investigator mode measurement diagnostics.</p> <p>When this option is activated, it is possible to have access to qualitative analysis of the noise source in measurement results for each channel through the WDM Investigator dashboard.</p> <ul style="list-style-type: none"> ▶ Qualitative analysis of the noise source in measurement results for each channel through the WDM Investigator dashboard ▶ Qualitative analysis of the PMD pulse spreading on live noncoherent signals <p>Note: <i>Not supported by the FTB-5240S module but supported by the FTB-5240S-P module.</i></p> <p>Note: <i>The WDM Investigator (Inv) software option is dependent on the InBand (InB) option. The InBand (InB) option must be enabled for the WDM Investigator (Inv) software option to work.</i></p>

Post-Processing Application

A post-processing, or offline version of the application is available for you to use on a conventional computer. This offline version has most of the module application, but does not allow you to perform acquisitions.

Conventions

Before using the product described in this guide, you should understand the following conventions:



WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in *death or serious injury*. Do not proceed unless you understand and meet the required conditions.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in *minor or moderate injury*. Do not proceed unless you understand and meet the required conditions.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in *component damage*. Do not proceed unless you understand and meet the required conditions.



IMPORTANT

Refers to information about this product you should not overlook.

2 **Safety Information**



WARNING

Do not install or terminate fibers while a light source is active. Never look directly into a live fiber and ensure that your eyes are protected at all times.




WARNING

The use of controls, adjustments and procedures other than those specified herein may result in exposure to hazardous situations or impair the protection provided by this unit.



IMPORTANT



When you see the following symbol on your unit , make sure that you refer to the instructions provided in your user documentation. Ensure that you understand and meet the required conditions before using your product.



IMPORTANT

Other safety instructions relevant for your product are located throughout this documentation, depending on the action to perform. Make sure to read them carefully when they apply to your situation.



CAUTION

The following symbol indicates that your unit is equipped with a laser source:



Safety Information

Your instrument is a Class 1 laser product in compliance with standards IEC 60825-1: 2007 and 21 CFR 1040.10, except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007. Invisible laser radiation may be encountered at the output port.

The following label indicates that a product contains a Class 1 source:



The maximum input power for the FTB-5240S/S-P Optical Spectrum Analyzer is ≤ 4 W. For more information on equipment ratings, refer to the user documentation for your platform.

3 **Getting Started with Your OSA**

Inserting and Removing Test Modules



CAUTION

Never insert or remove a module while the FTB-200 v2 is turned on. This will result in immediate and irreparable damage to both the module and unit.



CAUTION

To avoid damaging your unit, use it only with modules approved by EXFO.



WARNING


When the laser safety LED is flashing, at least one of your modules is emitting an optical signal. Please check all modules, as it might not be the one you are currently using.

Getting Started with Your OSA

Inserting and Removing Test Modules

To insert a module into the FTB-200 v2:

1. Turn off your unit.
2. Position the unit so that its front panel is facing you.




3. Take the module and place it vertically so that the retaining screw hole is at the left of the connector pins.



CAUTION

Inserting a module upside down could result in permanent damage to the module, as the connector pins might be bent.



4. Insert the protruding edges of the module into the grooves of the unit's module slot.
5. Push the module all the way to the bottom of the slot, until the retaining screw makes contact with the unit casing.
6. Place the unit so that its bottom panel is facing you.


Getting Started with Your OSA

Inserting and Removing Test Modules

7. While applying slight pressure to the module, lift the mobile part of the retaining screw and use it to turn the retaining screw clockwise until it is tightened.

This will secure the module into its “seated” position.

Turn retaining screws
clockwise




When you turn on the unit, the startup sequence will automatically detect the module.

To remove a module from the FTB-200 v2:

- 1.** Turn off your unit.
- 2.** Position the unit so that the bottom panel is facing you.
- 3.** Lift the mobile part of the retaining screw and use it to turn the retaining screw counterclockwise until it stops.

The module will be slowly released from the slot.

Turn retaining screws
counterclockwise




- 4.** Place the unit so that the top panel is facing you.

Getting Started with Your OSA

Inserting and Removing Test Modules

5. Hold the module by its sides or by the handle (*NOT by the connector*) and pull it out.



CAUTION

Pulling out a module by a connector could seriously damage both the module and connector. Always pull out a module by its casing.

6. Cover empty slots with the supplied protective covers.


Starting Module Applications

Your modules can be configured and controlled from their dedicated applications in Compact ToolBox.

To start a module application:

1. From Compact ToolBox, select the module to use.

It will turn blue to indicate that it is highlighted.



Getting Started with Your OSA


Starting Module Applications

- Under **Applications**, select an application, then press **Start**.

To start the Power Meter or Probe application:

From **Main Menu**, press **Power Meter** or **Probe**.

The main window (shown below) contains all the commands required to control the OSA:



Note: The illustrations in this user guide may differ slightly from those on your unit depending on the resolution and platform type.

4 **Preparing Your OSA for a Test**



IMPORTANT

For optimal test results, you should allow a minimum warm up period of two hours for your OSA before starting your tests.

Cleaning and Connecting Optical Fibers



IMPORTANT

To ensure maximum power and to avoid erroneous readings:

- Always inspect fiber ends and make sure that they are clean as explained below before inserting them into the port. EXFO is not responsible for damage or errors caused by bad fiber cleaning or handling.
- Ensure that your patchcord has appropriate connectors. Joining mismatched connectors will damage the ferrules.

To connect the fiber-optic cable to the port:

- 1.** Inspect the fiber using a fiber inspection microscope. If the fiber is clean, proceed to connecting it to the port. If the fiber is dirty, clean it as explained below.
- 2.** Clean the fiber ends as follows:
 - 2a.** Gently wipe the fiber end with a lint-free swab dipped in isopropyl alcohol.
 - 2b.** Use compressed air to dry completely.
 - 2c.** Visually inspect the fiber end to ensure its cleanliness.

Preparing Your OSA for a Test

Cleaning and Connecting Optical Fibers

3. Carefully align the connector and port to prevent the fiber end from touching the outside of the port or rubbing against other surfaces.

If your connector features a key, ensure that it is fully fitted into the port's corresponding notch.

4. Push the connector in so that the fiber-optic cable is firmly in place, thus ensuring adequate contact.

If your connector features a screwsleeve, tighten the connector enough to firmly maintain the fiber in place. Do not overtighten, as this will damage the fiber and the port.

Note: *If your fiber-optic cable is not properly aligned and/or connected, you will notice heavy loss and reflection.*


EXFO uses good quality connectors in compliance with EIA-455-21A standards.

To keep connectors clean and in good condition, EXFO strongly recommends inspecting them with a fiber inspection probe before connecting them. Failure to do so will result in permanent damage to the connectors and degradation in measurements.


Installing the EXFO Universal Interface (EUI)

The EUI fixed baseplate is available for connectors with angled (APC) or non-angled (UPC) polishing. A green border around the baseplate indicates that it is for APC-type connectors.

Green border
indicates APC
option




Bare metal
(or blue border)
indicates UPC
option



To install an EUI connector adapter onto the EUI baseplate:

- 1.** Hold the EUI connector adapter so the dust cap opens downwards.



- 2.** Close the dust cap in order to hold the connector adapter more firmly.
- 3.** Insert the connector adapter into the baseplate.
- 4.** While pushing firmly, turn the connector adapter clockwise on the baseplate to lock it in place.


Selecting a Test Mode

Your module gives you different ways to test all your DWDM systems:


- WDM: Allows you to analyze an optical link. By default, the WDM test mode is selected.
- Drift: Allows you to monitor an optical link for a fixed duration.
- DFB: Allows you to characterize a DFB laser source.
- Fabry-Perot (FP): Allows you to characterize a Fabry-Perot laser source.
- Spectral Transmittance: Allows you to characterize the spectral transmittance of optical components such as filters.
- EDFA: Allows you to characterize the performance of an Erbium Doped Fiber Amplifier (EDFA) using the OSA module in field deployed systems (NB measurement assumes transmission conditions).

To select a test mode:

1. From the **Main Menu**, press **Mode**.



2. Select the desired test mode. The DFB and FP sources are under the **Sources** item.



Once you select the mode, you will notice a against the selected mode and all the tabs on the main window and the main menu will change accordingly.

After selecting the test mode, you must configure it. You will find specific instructions for your test mode in the corresponding related chapters.

Preparing Your OSA for a Test

Switching Modes While a Trace is Open

Switching Modes While a Trace is Open

If you switch test modes while a trace is already on-screen, the trace will be loaded in the new selected mode and analyzed using the current analysis setup, if the test modes are compatible.

WDM, Spectral Transmittance and EDFA test modes are made to ease the switch between the modes. The table below indicates the equivalencies between the trace types. For example, an active trace in WDM mode becomes an output trace in EDFA mode, and vice-versa.

WDM	ST	EDFA
Active	Output	Output
Reference	Input	Input

Nulling Electrical Offsets

The offset nulling process provides a zero-power reference measurement, thus eliminating the effects of electronic offsets and dark current due to detectors.


Temperature and humidity variations affect the performance of electronic circuits and optical detectors. For this reason, EXFO recommends performing a nulling of the electrical offsets whenever environmental conditions change.

Nulling can be performed for all tests modes. In addition, a nulling is performed automatically each time you start the OSA application, and at regular intervals afterwards.

Note: *You cannot perform an offset nulling in the offline version of the application.*

To perform an offset nulling:

1. From the main window, select the **Acquisition** tab.




Preparing Your OSA for a Test

Nulling Electrical Offsets

2. Disconnect any incoming signal to obtain an optimal accuracy.
3. Press **Nulling**.

You are notified that the nulling is in progress in the status bar. Nulling should be completed in a few seconds.



Note: Several features, such as the **Start** button and **Discover**, are not available during the nulling process.

Performing User Calibration

Calibrating your module can help you achieve better results. It is particularly important when the measurement accuracy is critical or when your OSA has experienced unusual shock or vibrations. To reach the highest possible accuracy, you can perform a wavelength or power calibration. Your OSA allows you to modify and read the user calibration values, revert to the factory calibration, load and save the modified user calibration file. The user configuration file (*.txt) contains the reference and modified wavelength and power values.

You can perform user calibration in any test mode. Select a test mode as explained in *Selecting a Test Mode* on page 20, and follow the procedures mentioned below for performing user calibration.

Note: *The procedure for performing user calibration is the same for all test modes. The procedure is explained with WDM mode only in this document.*



IMPORTANT

For optimal results, you should allow a minimum warm up period of two hours for your OSA before performing user calibration.



IMPORTANT

You must clear the correction factor list before making new calibration measurements. If calibration measurements are made when user correction factors are inside the module, the latter will affect the measurements and the calibration results become inapplicable.

Note: *If you want to keep the correction factor list for a later use, save it under a different name in the folder.*


Note: *The user calibration feature is not available in the offline version of the OSA application.*

Preparing Your OSA for a Test


Performing User Calibration

To perform a user calibration:

1. Allow your unit to warm up.
2. From the **Main Menu**, press **Analysis Setup**.



3. Select the **Calibration** tab.




Note: *You cannot edit the power or wavelength values directly from the application. The modifications in the user calibration have to be made in a text file, and then it can be loaded in the application.*

Preparing Your OSA for a Test

Performing User Calibration

4. If user correction factors are in the system, press **Clear User Correction Factors from Module**, then confirm your choice.



5. Take measurements for your test mode.

6. Note the measurements to a .txt file using the following format:
 - The first column is the reference wavelengths, in nm.
 - The second column is the wavelength read by your module, in nm.
 - The third column is the reference power, in dBm.
 - The fourth column is the power read by your module, in dBm.

Note: *The columns are separated by a semi-colon (;). You can have up to 100 calibration points.*

Here is an example of a measurement file:

1310.154; 1310.167; -1.34; -1.55

1490.000; 1490.000; 1.09; 1.15

1551.334; 1551.298; -5.20; -5.45

1625.401; 1625.448; 0.00; 0.00


Note: *The decimal separator is a point (.). This format is independent of the regional settings.*

7. Save your .txt file in a location of your choice.


Preparing Your OSA for a Test

Performing User Calibration


8. Back in the **Calibration** tab on your unit, load the file using **Load Factors**.



9. Select the modified user calibration file and press **Open**.




The calibration values will replace the Correction factors list in the **Analysis setup - Calibration** window.




Preparing Your OSA for a Test

Performing User Calibration

10. Press **Write to Module** to apply the modified calibration values to the module.



- 11.** To verify that the calibration changes are properly applied to the module, press **Load from Module**.




Note: The **OK** and **Cancel** buttons do not have any impact on the calibration page or the correction factors inside the module.

Preparing Your OSA for a Test


Performing User Calibration

To save a user calibration:

1. From the **Main Menu**, press **Analysis Setup**.




2. Select the **Calibration** tab.



Preparing Your OSA for a Test

Performing User Calibration

3. Press **Save Factors**, to save the modified user calibration values.



Using the Autonaming Feature

Defining a file autonaming format will allow you to quickly and automatically name traces in a sequential order. The customized name appears when the file is saved using the Save As option. You can select which fields you want to include in the file name and the order in which they should be displayed.

The Link ID is used by the application to suggest a file name when you want to save the current acquisition. The link parameters are prefix and suffix values (file names) for the link IDs.

Note: *The autonaming feature is not available in the offline application.*


Note: *The procedure below uses the WDM test mode as an example, but the autonaming feature is available for all test modes.*

Preparing Your OSA for a Test


Using the Autonoming Feature

To customize the file name:

1. From the **Main Menu**, press **Preferences**.



2. Select the **File Name** tab.



3. Select which parameters you want to include in the file name from the list of available choices:


- Wavelength/frequency range: current wavelength/frequency acquisition range.
- Acquisition type: current acquisition type.
- Scan count: current number of scans in the acquisition tab.
- Link ID: prefix value for the link ID configured in the **Preferences-Information** tab.
- Cable ID: prefix value for the cable ID configured in the **Preferences-General** tab.
- Fiber ID: prefix value for the fiber ID configured in the **Preferences-General** tab.
- Location description: location description provided in the **Preferences-Information** tab.

Preparing Your OSA for a Test

Using the Autonaming Feature

4. Press the up or down arrows to change the order in which the field values will appear in the file name.

Based on your selection, a preview of the file name is displayed under **File name preview**. The field values are separated with an underscore (_).



5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default settings.

5 **Setting Up the Instrument in WDM Mode**

Before performing a spectral analysis in the WDM mode, you must set up the test application with the appropriate parameters, as explained in this chapter.


Select the WDM test mode as explained in *Selecting a Test Mode* on page 20 before setting up the WDM test parameters.

- The *preferences* are the result displayed in the graph and tables, as well as the job information and related comments saved with each file.
- The *analysis parameters* include the channel list details, pass-fail threshold settings and allows you to select the noise and power calculation methods.
- The *acquisition parameters* include the type of measurement you want to perform and the wavelength range.

See *Defining Preferences* on page 43, *Setting Up WDM Analysis Parameters* on page 59 and *Setting Up Acquisition Parameters* on page 86 for more details.

Setting Up the Instrument in WDM Mode

You can set up your unit in different manners, depending on your testing needs.

- The preferred way is to use the complete analysis setup parameters and complete the information in all tables, as explained in *Setting Up WDM Analysis Parameters* on page 59. This setup will be used for the next acquisition.
- The easiest way to set up the instrument, especially when the operator does not know in advance what to expect at the input of the module is to use the **Discover** button. After the **Discover** button has been pressed, a measurement and analysis will be performed according to the best setup determined by the instrument and this setup will be used for the next scan. This is explained in *Using the Discover Feature* on page 239.
- The most efficient way to set up the instrument is to use one of the favorites configurations, uploading a pre-customized acquisition and analysis setup configuration. The operator in the field only has to press the  button, select the appropriate configuration and press **Start**. As an example, a pre-customized configuration could be: “32 channels DWDM 50GHz”; “Toronto-Montreal CWDM” or “Vendor ABC DWDM ROADM 40Gb”. This is explained in *Managing Favorites* on page 250.
- You can also import the setup from the current trace. This method will take the data and channel information from the current trace and apply them in the corresponding tabs. For more information, see *Setting Up WDM Analysis Parameters* on page 59.

Defining Preferences

The preferences window allows you to set general information and comments on trace, set display parameters and customize the WDM results table.


Note: Only the *Display and WDM Results* tabs are available in offline mode.

Defining Trace Information

The trace information relates to the description of the job to be done, cable and job IDs, and any relevant information about what is being tested.

To enter general information:


1. From the **Main Menu**, press **Preferences**.



Setting Up the Instrument in WDM Mode

Defining Preferences

2. Select the **General** tab.



The screenshot shows a software window with a tabbed interface. The 'General' tab is selected and highlighted with a red circle. The window contains several input fields and a 'Clear' button. The fields are labeled as follows:

- Job ID: My Job
- Cable ID: 12_3343
- Fiber ID: (empty)
- Customer: (empty)
- Company: Your Company
- Operator: You
- Maintenance reason: (empty dropdown menu)


At the bottom of the window, there are 'OK' and 'Cancel' buttons, and a 'Clear' button is located above them.

3. Define the general parameters as needed.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Clear** to clear all the changes made in the **General** tab.

To enter link and location information:

1. From the Main Menu, press Preferences.




2. Select the Information tab.



Setting Up the Instrument in WDM Mode

Defining Preferences

3. Under **System and link information**, define the following parameters as needed:



- Link ID prefix: The prefix value for the link ID. You can enter any alphanumeric value.
- Starting value: The suffix increment starting value for the link ID. This value is incremented each time a new file is saved provided the **Auto Increment** option is selected.




IMPORTANT

If the Auto Increment option is not selected, you have to manually change the file name when saving the trace file, otherwise the application will overwrite the previously saved file.

- Orientation: The orientation of the link.
- System: Information about the system under test.

4. Under **Location Information**, define the following parameters as needed:



The screenshot shows a software window with several tabs: General, Information (selected), Comments, Display, WDM Results, and File Name. The 'Information' tab is active, displaying two sections: 'System and link information' and 'Location information'. The 'Location information' section is highlighted with a red rectangular box. It contains three fields: 'Network element' with a dropdown menu set to 'Transmitter', 'Test point' with a dropdown menu set to 'Input', and 'Description' with an empty text box. Below the 'Location information' section is a 'Restore Defaults' button. At the bottom of the window are 'OK' and 'Cancel' buttons.

- Network element: Sets the type of network element.
 - Test point: Sets the location where the test is performed on the link.
 - Description: Enter the description of location if required.
5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up the Instrument in WDM Mode


Defining Preferences

To enter comments:

1. From the **Main Menu**, press **Preferences**.



2. Select the **Comments** tab.



3. Enter your comments for the current trace.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Clear** to clear all the changes made in the **Comments** tab.

Setting Up the Instrument in WDM Mode


Defining Preferences

Defining Display Parameters


The application allows you to set display settings for the acquisition trace. You can set the spectral unit for the trace and the results table. You can also select the label that should appear on the peaks of the trace.

To define display parameters:


1. From the **Main Menu**, press **Preferences**.



2. Select the **Display tab.**




3. Select the spectral unit you want to work with, either nm or THz.



Setting Up the Instrument in WDM Mode

Defining Preferences


4. Select the label that will appear on the peaks in the graph, either the channel name, its number, or nothing.




Setting Up the Instrument in WDM Mode

Defining Preferences

Note: The channel name and channel number cannot be shown at the same time.



Channel numbers




Defined channel names

Setting Up the Instrument in WDM Mode


Defining Preferences

5. Select whether you want to show or hide the empty channels from the channel list in the **Results** tab.



Note: When selected, empty channels are shown on screen and in the report files.


6. Select whether you want to show the horizontal markers or the integrated power and the Δ trace in the marker toolbar.



Setting Up the Instrument in WDM Mode

Defining Preferences

7. Select the background color scheme for the graph as desired.



8. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Restore Defaults** to remove all the changes and apply the default values.

Customizing WDM Results Table

It is possible to select which results you would like to be displayed in the **Results** tab of your WDM tests.

To customize the results table:


1. From the **Main Menu**, press **Preferences**.



Setting Up the Instrument in WDM Mode

Defining Preferences

2. Select the **WDM Results** tab.



3. Select which parameters you want to display in the **Results** tab from the list of available choices:

- Name: name of channel.
- λ (Center wavelength/frequency): spectral center-of-mass for the peak in that channel.
- Signal Power: signal power for the selected channel (excludes noise).
- OSNR: optical signal to noise ratio, given by Signal power (according to the current calculation method, in dBm), minus Noise (according to the current calculation method, in dBm).
- Noise: noise level for the selected channel. The type of noise is indicated in front of the measurement (IEC, Fit, Inb, Inb nf).
- BW 3.00 dB: bandwidth measured by taking the width of a signal at 50 % linear power of the peak, or -3 dB from the peak.
- BW at x dB: bandwidth measured by taking the width of a signal at x dB from the peak.

- $\Delta\lambda/f$: deviation of the spectral center of mass for the peak in that channel.
 - λ/f Peak: spectral peak in that channel.
 - $\Delta\lambda/f$ Peak: deviation of the spectral peak in that channel.
4. Press the up or down arrows to change the order in which the columns will appear in the **Results** tab.
 5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up WDM Analysis Parameters

This section presents the various analysis settings for the application, particularly the channel list and settings. You can set the default channel parameters, channel list, global thresholds, default channel thresholds, manage favorite configurations and perform user calibration.

Note: *When you change the analysis setup parameters, the new settings are active as soon as you confirm your choice. The current trace is re-analyzed, and the analysis setup parameters will be applied to the global results and channel results for the following acquisitions.*


You can either set each parameter individually, or use parameters from the current trace and import them.

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

To import the parameters from the current trace:


1. Make sure that you have a trace on-screen.
2. From the **Main Menu**, press **Analysis Setup**.



Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

3. From any tab, press **Import from Trace**.



4. Press **OK** to confirm the changes.

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

Defining General Settings

The general analysis parameters for WDM acquisitions affect the calculation of the results. Any change you make to the settings affect future traces, or you can apply them to the active trace when reanalyzing it.




IMPORTANT

In the General tab, you can set the default channel parameters. Any channel found during an acquisition that is not defined in the channel list will be analyzed according to the default channel settings.

To define general settings:


1. From the Main Menu, press Analysis Setup.



Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

2. Select the **General** tab.



Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

- Under **Default channel settings**, define the following parameters as needed:

The screenshot shows the 'Default Thresholds' tab of the instrument's configuration dialog. The 'Default channel settings' section is highlighted with a red box. The 'Activate default channel' checkbox is checked. Other parameters include Channel width (50.0 GHz), Signal power calculation (Integrated signal power), Noise for OSNR (5th order poly fit), OSNR distance (100.0 GHz), and Noise region (100.0 GHz). Global analysis parameters include Peak detection level (-35.00 dBm), RBW for OSNR (Instrument's RBW), Wavelength offset (0.000 nm), Power offset (0.00 dB), and Bandwidth at (20.00 dB). Buttons for 'Import from Trace', 'OK', 'Cancel', and 'Restore Defaults' are visible.

- Clear the **Activate default channel** option to use the currently defined channel list for analysis. This reduces the analysis time by eliminating the peak detection over the complete spectral range. The peaks outside the defined channel list will not be analyzed.

- Channel width (GHz or nm): indicates the limit inside which the power values will be considered in the channel.

For default channels, the channel width that sets the limits of the channel, should be the same as the channel distance or smaller (channel distance is defined while creating a channel list). If the channel width is not compatible with the channel spacing, either a single peak may be found for two distinct channels and two analysis would be performed and displayed for that peak, or, it is possible that two peaks may be found within the same channel and be considered as one multi-peak signal. With this result, you can use markers to find the spacing between adjacent channels or to find the channel width.

- Snap to ITU Grid: When selected, each detected peak will be defined by the nearest ITU channel. The ITU grid is based on the selected channel width.
- Signal power calculation: indicates which calculation method to apply for signal power value.

Integrated signal power: The integrated signal power represents the sum of the power values included between the channel limits of this channel, minus the estimated noise contribution between the same boundaries. In some cases, for instance CATV signals, signals with high-frequency modulation, or signals with an inherent line width similar or larger than the OSA's resolution bandwidth, this calculation becomes a better estimation of the true signal power.

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

Peak signal power: The peak signal power represents the maximum power value inside the channel. Note that it differs a little from the peak measurement on the spectrum due to the fact that the estimated noise is subtracted to get the peak signal power.

Total channel power: The total channel power represents the sum of the integrated signal power and of the noise within the channel. The OSNR calculation is not performed when the signal power calculation type is the total channel power.

- **Noise for OSNR:** indicates which calculation method to use for OSNR value.

Fixed range IEC based (IEC): The IEC method uses the interpolation of noise measured on both sides of the signal to estimate the noise level. The position at which the noise is estimated from the center wavelength is given by the OSNR distance.


InBand (InB): The InBand method uses a series of scans having different polarization states to calculate the noise level under the peak (InBand).

InBand narrow filter (InB nf): The InBand narrow filter method uses additional processing to provide an accurate OSNR value for the narrow carved noise. This is because with narrow filters, the noise level under the peak is not uniform and the OSNR value depends on the processing width selected.

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

- **Fifth order polynomial fit (Fit):** The fifth order polyfit method calculates the noise curve and thus the signal to noise ratio. The OSA will approximate the noise curve using a fifth order polynomial fit. This fit definition relies on fit and exclusion zones. Only the points in the fit zones are used to calculate the fifth order polynomial fit. If you select the fifth order polyfit method, you have to define the fit and exclusion zones for your tests using the OSNR distance and noise region fields. The exclusion zone is indirectly obtained from the OSNR distance.




- **OSNR distance (GHz or nm):** Except for the fifth order polyfit selection, the OSNR distance is automatically set at the channel edge, that is, at half of the channel width from the center wavelength.
For the fifth order polyfit, the OSNR distance corresponds to the distance from the channel peak to the center of the fit zone. It is independent of the channel width.
- **Noise region:** The noise region, or fit zone, defines the region where the polynomial fit applies. Two identical regions are centered at the OSNR distance.

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters


4. Under **Global analysis parameters**, define the following parameters as needed:



- Peak detection level (dBm): indicates the minimum power level from where the peak can be considered as a signal.
- RBW for OSNR (nm): indicates the resolution bandwidth selected for the OSNR calculation. This parameter is generally set to 0.1 nm to allow for a common basis of comparison between different OSAs having different effective resolutions. The instrument's RBW value is written below the graph. This parameter does not actually have an effect on the acquisition, but is only a normalization factor used to provide the OSNR value in a standardized manner.

- **Wavelength offset (nm):** indicates the offset value applied on the wavelength. This does not replace a calibration performed at EXFO, but it can help you temporarily sharpen the specifications if you have determined that, for example, your modules are used beyond the normal allowed use. Entering a value in THz is not possible. When an offset is applied, it is indicated at the bottom of the graph ($\lambda \leftrightarrow$).
- **Power offset (dB):** indicates the offset value applied on the power. This does not replace a calibration performed at EXFO, but it can help you achieve the specifications if you have determined that, for example, your modules are used beyond the normal allowed use. When an offset is applied, it is indicated at the bottom of the graph ($P \leftrightarrow$).

To edit the power offset as a tap percentage, press the **Edit %** button.



The percentage value entered in **Edit percentage** will be converted to a corresponding equivalent value in dB.

- **Bandwidth at (dB):** Set the power level used, relative to the channel peak power, to compute the second bandwidth result.
- 5.** Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

Defining Global Thresholds

Any change you make to the global threshold settings affect future traces, or you can apply them to the active trace when reanalyzing it.

The application allows you to activate and deactivate the threshold functionality with a single control. When thresholds are globally enabled, the results are displayed with the Pass/Fail status based on various settings (global results, channel results). In addition, a global pass/fail status is also displayed in the **Global Results** tab (See *Global Results Tab* on page 270).

When thresholds are globally disabled, results are displayed without a Pass/Fail status and the Global pass/fail status will not be active in the **Global Results** tab. The **P/F** column under the results table will not be displayed.

The screenshot displays the 'Global Results' tab in the software interface. The main window is divided into several sections:

- Global Results Table:** A table listing various parameters and their values.
- Pass/fail status:** A section indicating the current status, which is 'Not Active'.
- Trace Info:** A section at the bottom providing details about the current trace, such as acquisition type, number of scans, and start/stop times.

Global Results	
Channel count	38
Empty channel count	0
Average signal power	-18.67 dBm
Signal power flatness	7.50 dB
Average OSNR	28.24 dB
OSNR flatness	9.11 dB
Total power in scan range	-2.73 dBm
Global Analysis Parameters	
Peak detection level	-35.00 dBm
RBW for OSNR	0.065 nm
Wavelength offset	0.000 nm
Power offset	0.00 dB
Bandwidth at	20.00 dB
Default Channel Parameters	

Trace Info	
Acquisition type:	InBand
Number of scans:	200
Spectral range start:	1520.000 nm
Spectral range stop:	1570.000 nm
User calibration:	Factory
Calibration date:	4/9/2009
Acquisition start time:	8/6/2009 6:42:35 AM
Acquisition stop time:	8/6/2009 6:44:56 AM

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

You can set your pass/fail threshold limits in different ways depending on the type of test you are performing.


Threshold Limit	Definition
None	No threshold limit is set. The results will be displayed without a Pass/Fail verdict.
Min. only	The threshold limit is set for a minimum value only. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or greater than the minimum threshold set. The verdict is declared as Fail (in red), when the value is below the minimum threshold set.
Max. only	The threshold limit is set for a maximum value only. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or less than the maximum threshold set. The verdict is declared as Fail (in red), when the value is above the maximum threshold set.
Min. and Max.	The threshold limit is set for the minimum and maximum value. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or within the minimum and maximum thresholds set. The Pass/Fail verdict is declared as Fail (in red), when the value is beyond the minimum or maximum thresholds set.
Use Default	When this limit is set, the corresponding threshold set for the default channels in the Analysis Setup tab will be applied to the channel.
Max. Deviation	The threshold limit is set for the deviation value. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or within the deviation threshold set. The Pass/Fail verdict is declared as Fail (in red), when the value is beyond deviation threshold set.

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

To define global thresholds:

1. From the Main Menu, press **Analysis Setup**.




2. Select the **Global Thresholds** tab.

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

3. Select the **Activate all thresholds** option to manually set the global threshold values. If this option is not selected, all the thresholds will be deactivated, results are displayed without a Pass/Fail status and Global pass/fail status are not active in the **Global Results** tab.



4. Enter values in the boxes as explained below:
 - Average signal power (dBm): the sum of the signal powers of all the peaks detected in the current acquisition, divided by the total number of peaks.
 - Signal power flatness (dB): the difference between the maximum and minimum signal power values of the detected peaks, in dB.
 - Average OSNR (dB): the sum of the entire OSNR of the peaks detected in the current acquisition, divided by the total number of peaks.
 - OSNR flatness (dB): the difference between the maximum and minimum OSNR values of the detected peaks, in dB.
 - Empty channel count: The number of empty channels from the channel list.

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

Defining Default Thresholds

Default thresholds will be applied to any channel found outside the channel list during the acquisition or re-analysis.

Note: *The default thresholds settings are enabled only when the **Activate all thresholds** option is selected in the **Global Thresholds** tab. For more information, see Defining Global Thresholds on page 70.*

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

You can set your pass/fail threshold limits in different ways depending on the type of test you are performing.


Threshold Limit	Definition
None	No threshold limit is set. The results will be displayed without a Pass/Fail verdict.
Min. only	The threshold limit is set for a minimum value only. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or greater than the minimum threshold set. The verdict is declared as Fail (in red), when the value is below the minimum threshold set.
Max. only	The threshold limit is set for a maximum value only. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or less than the maximum threshold set. The verdict is declared as Fail (in red), when the value is above the maximum threshold set.
Min. and Max.	The threshold limit is set for the minimum and maximum value. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or within the minimum and maximum thresholds set. The Pass/Fail verdict is declared as Fail (in red), when the value is beyond the minimum or maximum thresholds set.
Max. Deviation	The threshold limit is set for the deviation value. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or within the deviation threshold set. The Pass/Fail verdict is declared as Fail (in red), when the value is beyond deviation threshold set.

Setting Up the Instrument in WDM Mode


Setting Up WDM Analysis Parameters

To define default Thresholds:

1. From the Main Menu, press **Analysis Setup**.



2. Select the Default Thresholds tab.



3. Enter values in the boxes as explained below:

- Wavelength/Frequency (nm/GHz): the channel's central wavelength/frequency.
- Signal power (dBm): the signal power for the default channel (excludes noise).
- Noise (dBm): the level of the noise for the selected channel.
- OSNR (dB): the optical signal to noise ratio, given by Signal power (according to the current calculation method, in dBm) minus Noise (according to the current calculation method, in dBm).

4. Press **OK to save the changes and close the window, or press **Cancel** to exit without saving.**

Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters


Managing Channels

Testing DWDM systems involves characterizing multiple signals in a link. The application allows you to define channels using a channel editor or quickly generate them from the current data. You can also rapidly create a list of equally spaced channels. Once a channel list is created, you can modify it as needed. You can edit the analysis parameters for one channel or multiple channels.

While creating the channel list, some channels may overlap. When the channel widths are specified in nm, two channels are considered to be overlapping when more than 1.2 GHz (approximately) of frequency range is common between the two channels.

To add a channel list:


1. From the **Main Menu**, press **Analysis Setup**.



Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters


2. Select the **Channels** tab.
3. By default, the channel list is empty. Press **Add Channels**.



Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

4. Enter values in the boxes as explained below:



- Start range (nm or THz): starting range of the channel list.
- Stop range (nm or THz): ending range of the channel list.
- Channel center wavelength/frequency: spectral center-of-mass for the peak in that channel.

Note: When using the custom channel center wavelength option, the first channel will be centered at the Start Range, and the list will be created using channel distance and channel width.

- Channel distance (nm or GHz): distance between channels. The value of channel distance will be set depending on the selection made for the channel center wavelength option. The channel distance box will be enabled only when the channel center wavelength option is set to custom.
- Channel width (nm or GHz): limit inside which the power values will be considered in the channel. Integrated power is calculated on channel width.
- Name prefix: adds a prefix to the channel names.

- Starting value: sets the increment starting value for the channel name in the channel list.
- Increment value: sets the increment value for the channel name in the channel list.

5. Press **OK** to return to the **Channels** window, which now lists the added channels.

Note: *When new channels are added, the **Use Default thresholds** selection will be applied to the channel parameters.*

Note: *A warning message will be displayed if channels are overlapping, but the analysis can still be performed on overlapping channels. If any duplicate channels are added, a confirmation message will be displayed to overwrite the existing channels with the duplicate channels.*

6. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Note: *The application displays a message if more than 1000 channels are added. You can exit the **Analysis Setup** window only after deleting the extra channels from the channel list. You can delete the channels manually as required.*

Setting Up the Instrument in WDM Mode


Setting Up WDM Analysis Parameters

To edit the parameters of a specific channel:

1. From the **Main Menu**, press **Analysis Setup**.



2. Select the **Channels** tab.




3. Select the channel or channels to be modified in the channel list.

If you want the changes to be applied to all of your channels, press **Select All**. Channels can be selected one by one or all together. You can press **Unselect All** to clear all channel selections. To delete the selected channels, press **Delete**.

Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

4. Press Edit Selection.



Setting Up the Instrument in WDM Mode

Setting Up WDM Analysis Parameters

5. Modify the settings as needed. For more information about the settings, see *Defining General Settings* on page 62 and *Defining Default Thresholds* on page 74. If you leave a box empty, it will remain as it was before your changes. Modify appropriate settings.

The screenshot shows a dialog box for setting WDM analysis parameters. It is divided into two main sections: 'Analysis' and 'Thresholds'.
Analysis Section:
- Channel center: 192.7000 THz
- Channel name: 035
- Channel width: 100.0 GHz
- Signal power calculation: Integrated signal power
- Noise for OSNR: Fixed range IEC based
- OSNR distance: 50.0 GHz
- Noise region: 5.0 GHz
- A 'Restore Defaults' button is located at the bottom right of this section.
Thresholds Section:
- Frequency: 2.5 GHz
- Signal power: -45.00 dBm
- Noise: -99.99 dBm
- OSNR: 5.00 dB
- A 'Restore Defaults' button is located at the bottom right of this section.
At the bottom of the dialog box, there are buttons for '?', 'OK', and 'Cancel'.

6. Press **OK** to return to the **Channels** tab, which now contains the modified settings.
7. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Setting Up Acquisition Parameters

Before performing your test, you must set the acquisition type and parameters.

There are five types of acquisitions in WDM mode:

- **Single:** Spectral measurement is performed once. The results are displayed according to this measurement.
- **Averaging:** Spectral measurements are performed based on the number of scans that you have entered for this parameter. The trace will be displayed after each acquisition and averaged with the previous traces.
- **Real-Time:** In real-time acquisition, spectral measurements are performed continuously until you press **Stop**. No averaging is done for spectral measurements. The graph and results are refreshed after each acquisition.
- **InBand:** The InBand type acquisition will perform a series of scans in different polarization conditions in order to enable the InBand OSNR calculation.
- ***i*-InBand:** The *i*-InBand acquisition enables an adaptive intelligent InBand OSNR calculation that takes into account the multiple scans (up to 500) in various polarization conditions to determine the best available InBand analysis parameters for the signals under test on a per channel basis. With this acquisition type, you do not need to make difficult parameter setting choices (the InBand or InBand narrow filter and number of scans are automatically determined), especially when you are faced with complex system configurations.

Note: *The InBand and i-InBand option are available only if the module supports it and you have purchased the corresponding InB software option.*

Setting Up the Instrument in WDM Mode


Setting Up Acquisition Parameters

Before performing measurements on an optical spectrum, you must select the wavelength/frequency range to use. You can perform the scan on the full range, on spectral bands, or select a custom range.


Note: *The shorter the wavelength or frequency range, the faster the acquisition.*

To set parameters in the Acquisition tab:

1. From the main window, select the **Acquisition** tab.



2. Select the acquisition type.



Setting Up the Instrument in WDM Mode

Setting Up Acquisition Parameters


3. If you are performing an averaging type acquisition, enter the number of scans the unit will perform.

If you are performing an InBand type acquisition, either enter the number of scans or select a predefined number of scans the unit will perform.

Note: You cannot modify the number of scans count value if you are performing a single or real-time or i-InBand acquisition.

Note: In i-InBand mode, the scan count value is always set to 500.

4. Select the wavelength range for your acquisition.



You can select the wavelength range by entering the start and stop values or by selecting a range on the double slider.

To select the wavelength range using the double slider, move the left and right handles on the double slider or simply click on any band.

Note: You can select more than one adjoining ranges to include in your range, for example, S + C.

The wavelength range covered within these bands of the spectra are listed below.

- O band (original): 1255 to 1365 nm
- E band (extended): 1355 to 1465 nm
- S band (short wavelengths): 1455 to 1535 nm
- C band (conventional “erbium window”): 1525 to 1570 nm
- L band (long wavelengths): 1560 to 1630 nm
- U band (ultralong wavelengths): 1620 to 1650 nm.

6 **Setting Up the Instrument in Drift Mode**

Before performing a spectral analysis in the Drift mode, you must set up the test application with the appropriate parameters, as explained in this chapter.


Select the Drift test mode as explained in *Selecting a Test Mode* on page 20 before setting up the Drift test parameters.

- The *preferences* are the result displayed in the graph and tables, as well as the job information and related comments saved with each file.
- The *analysis parameters* include the channel list details, pass-fail threshold settings and allows you to select the noise and power calculation methods.
- The *acquisition parameters* include the type of measurement you want to perform and the wavelength range.

See *Defining Preferences* on page 93, *Setting Up Drift Analysis Parameters* on page 107 and *Setting Up Acquisition Parameters* on page 131 for more details.

Setting Up the Instrument in Drift Mode

You can set up your unit in different manners, depending on your testing needs.

- The preferred way is to use the complete analysis setup parameters and complete the information in all tables, as explained in *Setting Up Drift Analysis Parameters* on page 107. This setup will be used for the next acquisition.
- The easiest way to set up the instrument, especially when the operator does not know in advance what to expect at the input of the module is to use the **Discover** button. After the **Discover** button has been pressed, a measurement and analysis will be performed according to the best setup determined by the instrument and this setup will be used for the next scan. This is explained in *Using the Discover Feature* on page 239.
- The most efficient way to setup the instrument is to use one of the favorites configurations, uploading a pre-customized acquisition and analysis setup configuration. The operator in the field only has to press the  button, select the appropriate configuration and press **Start**. As an example, a pre-customized configuration could be: “32 channels DWDM 50GHz”; “Toronto-Montreal CWDM” or “Vendor ABC DWDM ROADM 40Gb”. This is explained in *Managing Favorites* on page 250.
- You can also import the setup from the current trace. This method will take the data and channel information from the current trace and apply them in the corresponding tabs. For more information, see *Setting Up Drift Analysis Parameters* on page 107.

Defining Preferences

The preferences window allows you to set general information and comments on trace, set display parameters and customize the drift results table.


Note: Only the **Display** and **Drift Results** tabs are available in offline mode.

Defining Trace Information

The trace information relates to the description of the job to be done, cable and job IDs, and any relevant information about what is being tested.

To enter general information:


1. From the **Main Menu**, press **Preferences**.



Setting Up the Instrument in Drift Mode

Defining Preferences

2. Select the **General** tab.



The screenshot shows a software window with a tabbed interface. The 'General' tab is selected and highlighted with a red circle. The window contains several input fields for defining parameters:

- Job ID: Your Job
- Cable ID: 343_34
- Fiber ID: (empty)
- Customer: Your customer
- Company: (empty)
- Operator: (empty)
- Maintenance reason: (empty dropdown menu)


At the bottom right of the main area is a 'Clear' button. At the bottom of the window are 'OK' and 'Cancel' buttons, along with a help icon on the left.

3. Define the general parameters as needed.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Clear** to clear all the changes made in the **General** tab.

To enter link and location information:

1. From the Main Menu, press Preferences.



2. Select the Information tab.



Setting Up the Instrument in Drift Mode

Defining Preferences

3. Under **System and link information**, define the following parameters as needed:

- Link ID prefix: prefix value for the link ID. You can enter any alphanumeric value.
- Starting value: suffix increment starting value for the link ID.

This value is incremented each time a new file is saved provided the **Auto Increment** option is selected.



IMPORTANT


If the Auto Increment option is not selected, you have to manually change the file name when saving the trace file, otherwise the application will overwrite the previously saved file.

- Orientation: orientation of the link.
 - System: information about the system under test.
4. Under **Location Information**, define the following parameters as needed:
 - Network element: Sets the type of network element.
 - Test point: Sets the location where the test is performed on the link.
 - Description: Enter the description of location if required.
 5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

To enter comments:


1. From the Main Menu, press Preferences.



Setting Up the Instrument in Drift Mode

Defining Preferences

2. Select the **Comments** tab.



3. Enter your comments for the current trace.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Clear** to clear all the changes made in the **Comments** tab.

Defining Display Parameters

The application allows you to set display settings for the acquisition trace. You can set the spectral unit for the trace and the results table. You can also select the label that should appear on the peaks of the trace.

To define display parameters:


1. From the **Main Menu**, press **Preferences**.




Setting Up the Instrument in Drift Mode

Defining Preferences


2. Select the **Display** tab.



3. Select the spectral unit you want to work with, either nm or THz.




4. Select the label that will appear on the peaks in the graph, either the channel name, its number, or nothing.




Setting Up the Instrument in Drift Mode

Defining Preferences

Note: The channel name and channel number cannot be shown at the same time.




Channel numbers




Defined channel names

5. Select whether you want to show or hide the empty channels from the channel list in the **Dashboard**, **Channel Graph**, **Channel Results** and **Channel History** tabs.




6. Select whether you want to show the horizontal markers or the integrated power trace in the marker toolbar.



Setting Up the Instrument in Drift Mode

Defining Preferences

7. Select the background color scheme for the graph as desired.



8. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Restore Defaults** to remove all the changes and apply the default values.

Customizing Drift Results Table

It is possible to select which results you would like to be displayed in the **Results** tab of your Drift tests.

To customize the results table:


1. From the **Main Menu**, press **Preferences**.



Setting Up the Instrument in Drift Mode

Defining Preferences

2. Select the **Drift Results** tab.



3. Select which parameters you want to display in the **Channel Graph** tab from the list of available choices:
 - Center wavelength/frequency: spectral center-of-mass for the peak in that channel.
 - Signal Power: signal power for the selected channel (excludes noise).
 - OSNR: Optical Signal to Noise Ratio, given by Signal power (according to the current calculation method, in dBm) minus Noise (according to the current calculation method, in dBm).
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up Drift Analysis Parameters


This section presents the various analysis settings for the application, particularly the channel list and settings. These settings are applied on subsequent acquisitions. You can set the channel list, global thresholds, default channel thresholds, channel parameters, manage favorite configurations and perform user calibration.

Note: *The analysis setup parameters will be applied to the global results and channel results, upon the next acquisition.*

You can either set each parameter individually, or use parameters from the current trace and import them.

To import the parameters from the current trace:


1. Make sure that you have a trace on-screen.
2. From the **Main Menu**, press **Analysis Setup**.



Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

3. From any tab, press **Import from Trace**.



4. Press **OK** to confirm the changes.

Defining General Settings

The general analysis parameters for drift acquisitions affect the calculation of the results. These calculations take place after an acquisition. If these settings are modified, they will be applied to the next acquisition.




IMPORTANT

In the General tab, you can set the default channel parameters. Any channel found during an acquisition that is not defined in the channel list will be analyzed according to the default channel settings.

To define general settings:


1. From the Main Menu, press Analysis Setup.



Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

2. Select the **General** tab.



- Under **Default channel settings**, define the following parameters as needed:

The screenshot shows a software interface with several tabs: General, Thresholds, Channels, Favorites, and Calibration. The 'General' tab is active. Under 'Default channel settings', there is a checkbox for 'Activate default channel' which is unchecked. Below it are fields for 'Channel width' (100.0 GHz), 'Signal power calculation' (Integrated signal power), 'Noise for OSNR' (Fixed range IEC based), 'OSNR distance' (50.0 GHz), and 'Noise region' (5.0 GHz). A red box highlights this section. Below this is the 'Global analysis parameters' section with fields for 'Peak detection level' (-60.00 dBm), 'RBW for OSNR' (0.100 nm), 'Wavelength offset' (0.000 nm), 'Power offset' (0.00 dB \approx 100.0%), and 'Bandwidth at' (20.00 dB). There is an 'Edit %' button next to the power offset field and a 'Restore Defaults' button at the bottom of the parameters section. At the very bottom of the window are buttons for 'Import from Trace', 'OK', and 'Cancel'.

- Clear the **Activate default channel** selection, to use the currently defined channel for analysis. This reduces the analysis time by eliminating the peak detection over the complete spectral range. The peaks outside the defined channel list will not be analyzed.

Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

- Channel width (GHz or nm): indicates the limit inside which the power values will be considered in the channel.

For default channels, the channel width that sets the limits of the channel, should be the same as the channel distance or smaller (channel distance is defined while creating a channel list). If the channel width is not compatible with the channel spacing, either a single peak may be found for two distinct channels and two analysis would be performed and displayed for that peak, or, it is possible that two peaks may be found within the same channel and be considered as one multi-peak signal. With this result, you can use markers to find the spacing between adjacent channels or to find the channel width.

- Snap to ITU Grid: When selected, each detected peak will be defined by the nearest ITU channel. The ITU grid is based on the selected channel width.
- Signal power calculation: indicates which calculation method to apply for signal power value.

Integrated signal power: The integrated signal power represents the sum of the power values included between the channel limits of this channel, minus the estimated noise contribution between the same boundaries. In some cases, for instance CATV signals, signals with high-frequency modulation, or signals with an inherent line width similar or larger than the OSA's resolution bandwidth, this calculation becomes a better estimation of the true signal power.

Peak signal power: The peak signal power represents the maximum power value inside the channel. Note that it differs a little from the peak measurement on the spectrum due to the fact that the estimated noise is subtracted to get the peak signal power.

Total channel power: The total channel power represents the sum of the integrated signal power and of the noise within the channel.


- **Noise for OSNR:** indicates which calculation method to use for OSNR value.

Fixed range IEC based (IEC): The IEC method uses the interpolation of noise measured on both sides of the signal to estimate the noise level. The position at which the noise is estimated from the center wavelength is given by the OSNR distance.

InBand (InB): The InBand method uses a series of scans having different polarization states to calculate the noise level under the peak (InBand).

InBand narrow filter (InB nf): The InBand narrow filter method uses additional processing to provide an accurate OSNR value for the narrow carved noise. This is because with narrow filters, the noise level under the peak is not uniform and the OSNR value depends on the processing width selected.

4. Under **Global analysis parameters**, define the following parameters as needed:




- Peak detection level (dBm): indicates the minimum power level from where the peak can be considered as a signal.
- RBW for OSNR (nm): indicates the resolution bandwidth selected for the OSNR calculation. This parameter is generally set to 0.1 nm to allow for a common basis of comparison between different OSAs having different effective resolutions. The instrument's RBW value is written below the graph. This parameter does not actually have an effect on the acquisition, but is only a normalization factor used to provide the OSNR value in a standardized manner.

Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

- ▶ Wavelength offset (nm): indicates the offset value applied on the wavelength. This does not replace a calibration performed at EXFO, but it can help you temporarily sharpen the specifications if you have determined that, for example, your modules are used beyond the normal allowed use. Entering a value in THz is not possible. When an offset is applied, it is indicated at the bottom of the graph ($\lambda \leftrightarrow$).
- ▶ Power offset (dB): indicates the offset value applied on the power. This does not replace a calibration performed at EXFO, but it can help you achieve the specifications if you have determined that, for example, your modules are used beyond the normal allowed use. When an offset is applied, it is indicated at the bottom of the graph (P \leftrightarrow).

To edit the power offset as a tap percentage, press the **Edit %** button.



The percentage value entered in **Edit percentage** will be converted to a corresponding equivalent value in dB.

- ▶ Bandwidth at (dB): Set the power level used, relative to the channel peak power, to compute the bandwidth.
5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Restore Defaults** to remove all the changes and apply the default values.

Defining Default Channel Thresholds

The thresholds will be applied to any channel found outside the channel list during the next acquisition. Thresholds will be applied to the channel results during the next acquisition.

The application allows you to activate and deactivate the threshold functionality with a single control. When thresholds are globally enabled, the results are displayed with the Pass/Fail status based on various settings.

When thresholds are globally disabled, results are displayed without a Pass/Fail status in the **Channel Graph** and **Channel History** tabs.



Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

When thresholds are globally disabled, the results in the **Channel Results** tab are also displayed without a Pass/Fail status.

Channel Results	
Channel number	1
Channel name	C_001
▲ Channel Results	
Center wavelength	1546.931 nm
Signal power	(I) -42.39 dBm
OSNR	22.43 dB
Noise	(IEC) -64.81 dBm
Bandwidth 3.00 dB	0.053 nm
Bandwidth 20.00 dB	0.352 nm
ENBW	0.033 nm
▲ Global Results	
Ref. empty channel count	0
▲ Global Analysis Parameters	
Peak detection level	-60.00 dBm
RBW for OSNR	0.100 nm

Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

You can set your pass/fail threshold limits in different ways depending on the type of test you are performing.


Threshold Limit	Definition
None	No threshold limit is set. The results will be displayed without a Pass/Fail verdict.
Min only	The threshold limit is set for a minimum value only. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or greater than the minimum threshold set. The verdict is declared as Fail (in red), when the value is below the minimum threshold set.
Max only	The threshold limit is set for a maximum value only. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or less than the maximum threshold set. The verdict is declared as Fail (in red), when the value is above the maximum threshold set.
Min and Max	The threshold limit is set for the minimum and maximum value. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or within the minimum and maximum thresholds set. The Pass/Fail verdict is declared as Fail (in red), when the value is beyond the minimum or maximum thresholds set.
Max. Deviation	The threshold limit is set for the deviation value. The Pass/Fail verdict is declared as Pass (in green), when the value is equal to or within the deviation threshold set. The Pass/Fail verdict is declared as Fail (in red), when the value is beyond deviation threshold set.

Setting Up the Instrument in Drift Mode


Setting Up Drift Analysis Parameters

To define the default channel thresholds:

1. From the Main Menu, press **Analysis Setup**.




2. Select the **Thresholds** tab.



Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

3. Select the **Activate all thresholds** option to manually set the channel threshold values. If this option is not selected, all the thresholds will be deactivated, results are displayed without a Pass/Fail status in the **Channel Graph**, **Channel History** and **Channel Results** tabs.



4. Enter values in the boxes as explained below:
 - Wavelength/Frequency (nm/GHz): central wavelength/frequency of the channel.
 - Signal power (dBm): signal power for the selected channel (excludes noise).
 - OSNR (dB): Optical Signal to Noise Ratio, given by Signal power (according to the current calculation method, in dBm) minus Noise (according to the current calculation method, in dBm).
5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.


Managing Channels

Testing DWDM systems involves characterizing multiple signals in a link. The application allows you to define channels using a channel editor or quickly generate them from the current data. You can also rapidly create a list of equally spaced channels. Once a channel list is created, you can modify it as needed. You can edit the analysis parameters for one channel or multiple channels.

While creating the channel list, some channels may overlap. When the channel widths are specified in nm, two channels are considered to be overlapping when more than 1.2 GHz (approximately) of frequency range is common between the two channels.

To add a channel list:


1. From the **Main Menu**, press **Analysis Setup**.




Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

2. Select the **Channels** tab.
3. By default, the channel list is empty. Press **Add Channels**.



4. Enter values in the boxes as explained below:



- Start range (nm or THz): starting range of the channel list.
- Stop range (nm or THz): ending range of the channel list.
- Channel center wavelength/frequency: spectral center-of-mass for the peak in that channel.

Note: When using the custom channel center wavelength option, the first channel will be centered at the Start Range, and the list will be created using channel distance and channel width.

Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

- Channel distance (nm or GHz): distance between the channels. The value of channel distance will be set depending on the selection made for the channel center wavelength option. The channel distance box will be enabled only when the channel center wavelength option is set to custom.
 - Channel width (nm or GHz): limit inside which the power values will be considered in the channel. Integrated power is calculated on channel width.
 - Name prefix: adds prefix to the channel names.
 - Starting Value: increment starting value for the channel name in the channel list.
 - Increment value: increment value for the channel name in the channel list.
5. Press **OK** to return to the **Channels** window, which now lists the added channels.

Note: *When new channels are added, the Use Default thresholds will be applied to the channel parameters.*

Note: *A warning message will be displayed if any channels are overlapping, but the analysis can still be performed on overlapping channels. If any duplicate channels are added, a confirmation message will be displayed to overwrite the existing channels with the duplicate channels.*

6. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Note: *The application displays a message if more than 1000 channels are added. You can exit the **Analysis Setup** window only after deleting the extra channels from the channel list. You can delete the channels manually as required.*

Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

To edit the parameters of a specific channel:


1. From the Main Menu, press Analysis Setup.



Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

2. Select the Channels tab.




Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

3. Select the channel or channels to be modified in the channel list.

If you want the changes to be applied to all of your channels, press **Select All**. Channels can be selected one by one or all together. You can press **Unselect All** to clear all channel selections. To delete the selected channels, press **Delete**.

4. Press **Edit Selection**.



Setting Up the Instrument in Drift Mode

Setting Up Drift Analysis Parameters

5. Modify the settings as needed. For more information about the settings, see *Managing Channels on page 123*. If you leave a box empty, it will remain as it was before your changes. Modify appropriate settings.

The screenshot shows a configuration window with the following fields and values:

- Channel center: 1531.898 nm
- Channel name: 005
- Channel width: 100.0 GHz
- Signal power calculation: Integrated signal power
- Noise for OSNR: Fixed range IEC based
- OSNR distance: 50.0 GHz
- Noise region: 5.0 GHz

A "Restore Defaults" button is located below the analysis parameters.

The "Thresholds" section contains the following table:

	Min.	Max.
Wavelength		0.020 nm
Signal power	-45.00	15.00 dBm
OSNR	5.00	60.00 dB

6. Press **OK** to return to the **Channels** tab, which now contains the modified settings.
7. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Setting Up Acquisition Parameters

Before performing your test, you must set the acquisition type and parameters from the **Acquisition** tab and other parameters from the **Drift Settings** tab.

There are three types of acquisitions in Drift mode: single, averaging and InBand.

- **Single:** Spectral measurement is performed once. The results are displayed according to this measurement.
- **Averaging:** Spectral measurements are performed based on the number of scans that you have entered for this parameter. The trace will be displayed after each acquisition and averaged with the previous traces.
- **InBand:** The InBand type acquisition will perform a series of scans in different polarization conditions in order to enable the InBand OSNR calculation.

Note: *The InBand option is available only if the module supports it.*

Before performing measurements on an optical spectrum, you must select the wavelength/frequency range to use. You can perform the scan on the full range, on spectral bands, or select a custom range.

Note: *The shorter the wavelength or frequency range, the faster the acquisition.*

You can configure the delay, sampling and total duration for a drift measurement. You can also configure the drift files name and select a location where it should be saved.


The application allows you to perform a trial scan while setting up the drift measurement.

Setting Up the Instrument in Drift Mode


Setting Up Acquisition Parameters

To set parameters in the Acquisition tab:

1. From the main window, select the **Acquisition** tab.



2. Select the acquisition type.




3. If you are performing an averaging type acquisition, enter the number of scans the unit will perform.

If you are performing an InBand type acquisition, either enter the number of scans or select a predefined number of scans the unit will perform.

Note: You cannot modify the number of scans count value if you are performing a single acquisition.

4. Select the wavelength range for your acquisition.



You can select the wavelength range by entering the start and stop values or by selecting a range on the double slider.

To select the wavelength range using the double slider, move the left and right handles on the double slider or simply click on any band.

Note: You can select more than one adjoining ranges to include in your range, for example, S + C.

Setting Up the Instrument in Drift Mode


Setting Up Acquisition Parameters

The wavelength range covered within these bands of the spectra are listed below.


- O band (original): 1255 to 1365 nm
- E band (extended): 1355 to 1465 nm
- S band (short wavelengths): 1455 to 1535 nm
- C band (conventional “erbium window”): 1525 to 1570 nm
- L band (long wavelengths): 1560 to 1630 nm
- U band (ultralong wavelengths): 1620 to 1650 nm.

To set parameters in the Drift Settings tab:

1. From the main window, select the **Drift Settings** tab.




2. Set a delay unit and count before taking the first acquisition in a drift measurement. The application will wait for this time before taking the first acquisition of a drift measurement.




Setting Up the Instrument in Drift Mode

Setting Up Acquisition Parameters

3. Select a sampling unit and enter a sampling count to configure a time that should be elapsed between the start of each acquisition during a drift measurement.




4. Select a duration unit and enter a duration count to configure the total duration of a drift measurement.



5. Enter a drift file name that should be used to save the drift file.


Note: This is not available in offline mode.



Setting Up the Instrument in Drift Mode

Setting Up Acquisition Parameters

6. Select a location where the drift file should be saved.



7. Select whether you want to keep all of the historical traces in the subfolder, keep only the significant ones, or keep none. The historical traces are stored in separate *.osawdm files.


A significant event is when

- a value from a given channel has crossed its threshold (going from pass to fail).
- there is no signal power in a given channel.

These historical files are stored in a dedicated folder having the same name as the associated drift measurement file name.

Note: You can have a maximum of 3 significant traces per channel.


Note: This option is not available in offline mode.



Setting Up the Instrument in Drift Mode

Setting Up Acquisition Parameters

8. To test your parameters, return to the **Acquisition** tab. Press **Trial Scan** to perform a trial acquisition.



When a trial acquisition is running, the **Start** button is disabled. You are notified that the acquisition is in progress in the status bar.

The trial scan is performed using the analysis setup parameters. When the acquisition is complete, the resulting acquisition is displayed in the **WDM Graph** tab and **Channel Results** tab. The **Channel History** tab displays results as if only time 0:00 was available. The other drift mode tabs are empty (**Dashboard**, **Channel Graph**).

Setting Up the Instrument in Drift Mode

Building a Custom Drift Measurement

Building a Custom Drift Measurement

You can build a drift measurement using a WDM measurement you already have as a reference. The selected channels and thresholds can be imported from the analysis setup or the reference measurement.

A custom drift measurement is particularly useful for offline processing of your data over time and comparing result variations.

The WDM measurements you add must meet specific criteria to be included in the custom build. The table below describes those compatibility criteria.

Note: *Files that are not compatible will automatically be rejected from the custom build measurement.*

Criteria	Test	Compatibility Status
Acquisition type	Target WDM measurement acquisition type differs from drift reference trace acquisition type	Compatible with warnings
Acquisition number of scans	Target WDM measurement acquisition number of scans differs from drift reference trace acquisition number of scans.	Compatible with warnings
Spectral range	<ul style="list-style-type: none">➤ Target WDM measurement acquisition spectral range only partially overlaps spectral range of drift reference trace.➤ There is no overlap between target WDM measurement spectral range and drift reference trace spectral range.	<ul style="list-style-type: none">➤ Compatible with warnings➤ Incompatible

Setting Up the Instrument in Drift Mode

Building a Custom Drift Measurement

Criteria	Test	Compatibility Status
Acquisition start time	<ul style="list-style-type: none"> ➤ Target WDM measurement acquisition start time is identical to another WDM measurement (including the drift reference trace) acquisition time. 	<ul style="list-style-type: none"> ➤ Compatible with warnings
	<ul style="list-style-type: none"> ➤ Target WDM measurement acquisition start time overlaps with another WDM measurement (including the drift reference trace) acquisition time range. 	<ul style="list-style-type: none"> ➤ Incompatible
Calibration type (user/factory)	Target WDM measurement instrument's calibration type differs from drift reference trace instrument's calibration type.	Compatible with warnings
Calibration date	Target WDM measurement instrument's calibration date differs from drift reference trace instrument's calibration date	Compatible with warnings
Instrument's model	Target WDM measurement instrument's model differs from drift reference trace instrument's model	Compatible with warnings
Instrument's serial number	Target WDM measurement instrument's serial number differs from drift reference trace instrument's serial number	Compatible with warnings
Instrument's RBW	Target WDM measurement instrument's RBW differs from drift reference trace instrument's RBW	Compatible with warnings


Setting Up the Instrument in Drift Mode

Building a Custom Drift Measurement

Criteria	Test	Compatibility Status
Power offset	Target WDM measurement power offset differs from drift reference trace power offset	Compatible with warnings
Wavelength offset	Target WDM measurement wavelength offset differs from drift reference trace wavelength offset	Compatible with warnings
Noise measurement	Target WDM measurement acquired trace data does not support configured noise measurement analysis parameter. (This criteria is specific for In-Band noise measurement against IEC acquired data)	Compatible with warnings

To build a custom drift measurement:


- 1.** If you have not done so already, select the Drift test mode.
- 2.** From the main window, select **Custom Build**.
- 3.** Select the reference trace you want to use to build the measurement, then click **Next**.



Setting Up the Instrument in Drift Mode

Building a Custom Drift Measurement

4. Select whether you want to import the analysis setup from the selected reference file, or use the settings currently set in your application, then click **Next**.



5. Enter, or review if they were imported, the general details for your measurement. See *Defining General Settings* on page 109 for details on each item.

Adjust analysis setup general parameters

Default: channel settings

Activate default channel

Channel width: 50.0 GHz Snap to ITU grid

Signal power calculation: Integrated signal power

Noise for OSNR: InBand narrow filter

OSNR distance: GHz

Noise region: GHz

Global analysis parameters

Peak detection level: -35.00 dBm

RBW for OSNR: Instrument's RBW

Bandwidth at: 20.00 dB

Restore Defaults

< Back Next > Cancel

6. Click **Next**.

Setting Up the Instrument in Drift Mode

Building a Custom Drift Measurement

7. If desired, adjust the threshold settings for your measurement. For details on each item, see *Defining Default Channel Thresholds* on page 117. When you are done, click **Next**.

Adjust analysis setup threshold parameters

Activate all thresholds

Default channel

	Min.	Max.	
Max. deviation Wavelength		0.020	nm
Min. and max. Signal power	-45.00	15.00	dBm
Min. and max. OSNR	5.00	60.00	dB


Restore Defaults

< Back Next > Cancel

Setting Up the Instrument in Drift Mode

Building a Custom Drift Measurement


8. Select which channels are to be included in the drift measurement. For details on each item, see *Managing Channels* on page 123. When you are done, click **Next**.




Setting Up the Instrument in Drift Mode

Building a Custom Drift Measurement

9. Add one or more measurement files at this point, then click **Next**.



- 10.** Before starting the measurement process, you can select what to do with the historical traces (keep them all, keep only the significant ones, or keep none), set the drift file name and its location.



- 11.** Once you are ready, click **Build**.

Once the process is complete, you can navigate through the results of the built drift.

7 **Setting Up the Instrument in DFB Mode**

Before performing a spectral analysis in the DFB mode, you must set up your OSA module and the test application with the appropriate parameters, as explained in this chapter.

Select the DFB test mode as explained in *Selecting a Test Mode* on page 20 before setting up the DFB test parameters.

- The *preferences* are the result displayed in the graph and tables, as well as the job information and related comments saved with each file.
- The *acquisition parameters* include the type of measurement you want to perform and the wavelength range.

See *Defining Preferences* on page 150 and *Setting Up Acquisition Parameters* on page 160 for more details.

Setting Up the Instrument in DFB Mode

Defining Preferences

Defining Preferences

The preferences window allows you to set general information and comments on trace and set display parameters.


Note: *In offline mode, only the **Display** tab is available.*

Defining Trace Information

The trace information relates to the description of the job to be done, cable and job IDs, and any relevant information about what is being tested.

To enter general information:

1. From the **Main Menu**, press **Preferences**.



2. Select the **General** tab.

The screenshot shows a software window with a tabbed interface. The 'General' tab is selected and highlighted with a red circle. The 'General' tab contains the following fields and values:

Field	Value
Job ID:	My Job
Cable ID:	12_334
Fiber ID:	
Customer:	Your Customer
Company:	
Operator:	You
Maintenance reason:	

At the bottom right of the form area is a 'Clear' button. At the bottom of the window are 'OK' and 'Cancel' buttons.

3. Define the general parameters as needed.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Clear** to clear all the changes made in the **General** tab.

Setting Up the Instrument in DFB Mode


Defining Preferences

To enter link and location information:

1. From the **Main Menu**, press **Preferences**.



2. Select the **Information** tab.



3. Under **System and link information**, define the following parameters as needed:

- Link ID prefix: prefix value for the link ID. You can enter any alphanumeric value.
- Starting value: suffix increment starting value for the link ID.

This value is incremented each time a new file is saved provided the **Auto Increment** option is selected.



IMPORTANT

If the Auto Increment option is not selected, you have to manually change the file name when saving the trace file, otherwise the application will overwrite the previously saved file.

- Orientation: orientation of the link.
 - System: information about the system under test.
4. Under **Location Information**, define the following parameters as needed:
 - Network element: type of network element.
 - Test point: where the test is performed on the link.
 - Description: Enter the description of location if required.
 5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up the Instrument in DFB Mode


Defining Preferences

To enter comments:

1. From the **Main Menu**, press **Preferences**.



2. Select the **Comments** tab.



3. Enter your comments for the current trace.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Clear** to clear all the changes made in the **Comments** tab.

Setting Up the Instrument in DFB Mode


Defining Preferences

Defining Display Parameters


The application allows you to set display settings for the acquisition trace. You can set the spectral unit for the trace and the results table.

To define display parameters:

1. From the **Main Menu**, press **Preferences**.




2. Select the **Display** tab.




Setting Up the Instrument in DFB Mode

Defining Preferences


3. Select the spectral unit you want to work with, either nm or THz.



4. Select whether you want to show the horizontal markers or the integrated power in the marker toolbar.



5. Select the background color scheme for the graph as desired.



6. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up Acquisition Parameters

Before performing your test, you must set the acquisition type and parameters.

There are three types of acquisitions in DFB mode:

- **Single:** Spectral measurement is performed once. The results are displayed according to this measurement.
- **Averaging:** Spectral measurements are performed based on the number of scans that you have entered for this parameter. The trace will be displayed after each acquisition and averaged with the previous traces.
- **Real-Time:** In real-time acquisition, spectral measurements are performed continuously until you press **Stop**. No averaging is done for spectral measurements. The graph and results are refreshed after each acquisition.


Before performing measurements on an optical spectrum, you must select the wavelength/frequency range to use. You can perform the scan on the full range, on spectral bands, or select a custom range.

Note: *The shorter the wavelength or frequency range, the faster the acquisition.*


Note: *The **Acquisition** tab is not available in offline mode.*

To set parameters in the Acquisition tab:

1. From the main window, select the **Acquisition** tab.



2. Select the acquisition type.




3. If you are performing an averaging-type acquisition, enter the number of scans the unit will perform.

Note: You cannot modify the number of scans count value if you are performing a single or real-time acquisition.

Setting Up the Instrument in DFB Mode

Setting Up Acquisition Parameters

4. Select the wavelength range for your acquisition.



You can select the wavelength range by entering the start and stop values or by selecting a range on the double slider.

To select the wavelength range using the double slider, move the left and right handles on the double slider or simply click on any band.

Note: *You can select more than one adjoining ranges to include in your range, for example, S + C.*

The wavelength range covered within these bands of the spectra are listed below.

- O band (original): 1255 to 1365 nm
- E band (extended): 1355 to 1465 nm
- S band (short wavelengths): 1455 to 1535 nm
- C band (conventional “erbium window”): 1525 to 1570 nm
- L band (long wavelengths): 1560 to 1630 nm
- U band (ultralong wavelengths): 1620 to 1650 nm.

8 **Setting Up the Instrument in FP Mode**

Before performing a spectral analysis in the FP mode, you must set up your OSA module and the test application with the appropriate parameters, as explained in this chapter.

Select the FP test mode as explained in *Selecting a Test Mode* on page 20 before setting up the FP test parameters.

- The *preferences* are the result displayed in the graph and tables, as well as the job information and related comments saved with each file.
- The *acquisition parameters* include the measurement you want to perform and the wavelength range.

See *Defining Preferences* on page 164 and *Setting Up Acquisition Parameters* on page 173 for more details.

Setting Up the Instrument in FP Mode

Defining Preferences

Defining Preferences

The preferences window allows you to set general information and comments on trace and set display parameters.


Note: *In offline mode, only the **Display** tab is available.*

Defining Trace Information

The trace information relates to the description of the job to be done, cable and job IDs, and any relevant information about what is being tested.

To enter general information:

1. From the **Main Menu**, press **Preferences**.



2. Select the **General** tab.

The screenshot shows a software window with five tabs: General, Information, Comments, Display, and File Name. The 'General' tab is selected and highlighted with a red circle. The 'General' tab contains the following fields and values:

Field	Value
Job ID:	My Job
Cable ID:	12_334
Fiber ID:	
Customer:	Your Customer
Company:	
Operator:	You
Maintenance reason:	

At the bottom right of the form area is a 'Clear' button. At the bottom of the window are 'OK' and 'Cancel' buttons.

3. Define the general parameters as needed.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Clear** to clear all the changes made in the **General** tab.

Setting Up the Instrument in FP Mode


Defining Preferences

To enter link and location information:

1. From the **Main Menu**, press **Preferences**.



2. Select the **Information** tab.



3. Under **System and link information**, define the following parameters as needed:

- Link ID prefix: prefix value for the link ID. You can enter any alphanumeric value.
- Starting value: suffix increment starting value for the link ID.

This value is incremented each time a new file is saved provided the **Auto Increment** option is selected.



IMPORTANT

If the Auto Increment option is not selected, you have to manually change the file name when saving the trace file, otherwise the application will overwrite the previously saved file.

- Orientation: orientation of the link.
 - System: information about the system under test.
4. Under **Location Information**, define the following parameters as needed:
- Network element: type of network element.
 - Test point: where the test is performed on the link.
 - Description: Enter the description of location if required.
5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up the Instrument in FP Mode


Defining Preferences

To enter comments:

1. From the **Main Menu**, press **Preferences**.



2. Select the **Comments** tab.



3. Enter your comments for the current trace.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Clear** to clear all the changes made in the **Comments** tab.

Setting Up the Instrument in FP Mode


Defining Preferences

Defining Display Parameters


The application allows you to set display settings for the acquisition trace. You can set the spectral unit for the trace and the results table.

To define display parameters:


1. From the **Main Menu**, press **Preferences**.



2. Select the **Display** tab.




3. Select the spectral unit you want to work with, either nm or THz.




Setting Up the Instrument in FP Mode

Defining Preferences

4. Select whether you want to show the horizontal markers or the integrated power trace in the marker toolbar.



5. Select the background color scheme for the graph as desired.



6. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up Acquisition Parameters

Before performing your test, you must set the acquisition type and parameters.

There are three types of acquisitions in FP mode:

- **Single:** Spectral measurement is performed once. The results are displayed according to this measurement.
- **Averaging:** Spectral measurements are performed based on the number of scans that you have entered for this parameter. The trace will be displayed after each acquisition and averaged with the previous traces.
- **Real-Time:** In real-time acquisition, spectral measurements are performed continuously until you press **Stop**. No averaging is done for spectral measurements. The graph and results are refreshed after each acquisition.

Before performing measurements on an optical spectrum, you must select the wavelength/frequency range to use. You can perform the scan on the full range, on spectral bands, or select a custom range.

Note: *The shorter the wavelength or frequency range, the faster the acquisition.*


Note: *The **Acquisition** tab is not available in offline mode.*

Setting Up the Instrument in FP Mode


Setting Up Acquisition Parameters

To set parameters in the Acquisition tab:

1. From the main window, select the **Acquisition** tab.




2. Select the acquisition type.



3. If you are performing an averaging type acquisition, enter the number of scans the unit will perform.

Note: You cannot modify the number of scans count value if you are performing a single or real-time acquisition.

4. Select the wavelength range for your acquisition.



You can select the wavelength range by entering the start and stop values or by selecting a range on the double slider.

To select the wavelength range using the double slider, move the left and right handles on the double slider or simply click on any band.

Note: You can select more than one adjoining ranges to include in your range, for example, S + C.

The wavelength range covered within these bands of the spectra are listed below.

- O band (original): 1255 to 1365 nm
- E band (extended): 1355 to 1465 nm
- S band (short wavelengths): 1455 to 1535 nm
- C band (conventional “erbium window”): 1525 to 1570 nm
- L band (long wavelengths): 1560 to 1630 nm
- U band (ultralong wavelengths): 1620 to 1650 nm.

9

Setting Up the Instrument in Spectral Transmittance Mode

Before performing a spectral analysis in the Spectral Transmittance mode, you must set up your OSA module and the test application with the appropriate parameters, as explained in this chapter.

Select the Spectral Transmittance test mode as explained in *Selecting a Test Mode* on page 20 before setting up the test parameters.

- The *preferences* are the result displayed in the graph and tables, as well as the job information and related comments saved with each file.
- The *analysis parameters* include the channel details, the nominal wavelength or frequency and the input and output offset values.
- The *acquisition parameters* include the type of measurement you want to perform and the wavelength range.

See *Defining Preferences* on page 178 , *Setting Up Spectral Transmittance Analysis Parameters* on page 187 and *Setting Up Acquisition Parameters* on page 195 for more details.

Defining Preferences

The preferences window allows you to set general information and comments on trace and set display parameters.


Note: *In offline mode, only the **Display** tab is available.*

Defining Trace Information


The trace information relates to the description of the job to be done, cable and job IDs, and any relevant information about what is being tested.

To enter general information:

1. From the **Main Menu**, press **Preferences**.



2. Select the **General** tab.



The screenshot shows a software window with a tabbed interface. The 'General' tab is selected and highlighted with a red circle. The 'General' tab contains the following fields and values:

Field	Value
Job ID:	My Job
Cable ID:	12_334
Fiber ID:	
Customer:	Your Customer
Company:	
Operator:	You
Maintenance reason:	

A 'Clear' button is located at the bottom right of the form area. At the bottom of the window are 'OK' and 'Cancel' buttons.

3. Define the general parameters as needed.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Clear** to clear all the changes made in the **General** tab.

Setting Up the Instrument in Spectral Transmittance Mode


Defining Preferences

To enter link and location information:

1. From the **Main Menu**, press **Preferences**.



2. Select the **Information** tab.



3. Under **System and link information**, define the following parameters as needed:

- Link ID prefix: prefix value for the link ID. You can enter any alphanumeric value.
- Starting value: suffix increment starting value for the link ID.

This value is incremented each time a new file is saved provided the **Auto Increment** option is selected.



IMPORTANT

If the Auto Increment option is not selected, you have to manually change the file name when saving the trace file, otherwise the application will overwrite the previously saved file.

- Orientation: orientation of the link.
 - System: information on the system under test.
4. Under **Location Information**, define the following parameters as needed:
- Network element: network element type.
 - Test point: where the test is performed on the link.
 - Description: a description of the location, if required.
5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up the Instrument in Spectral Transmittance Mode


Defining Preferences

To enter comments:

1. From the **Main Menu**, press **Preferences**.



2. Select the **Comments** tab.



3. Enter your comments for the current trace.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Clear** to clear all the changes made in the **Comments** tab.

Setting Up the Instrument in Spectral Transmittance Mode


Defining Preferences

Defining Display Parameters


The application allows you to set display settings for the acquisition trace. You can set the spectral unit for the trace and the results table.

To define display parameters:

1. From the Main Menu, press **Preferences**.




2. Select the **Display tab.**




Setting Up the Instrument in Spectral Transmittance Mode

Defining Preferences

3. Select the spectral unit you want to work with, either nm or THz.




4. Select whether you want to show the horizontal markers or the integrated power and the Δ trace in the marker toolbar.



Setting Up the Instrument in Spectral Transmittance Mode

Setting Up Spectral Transmittance Analysis Parameters

5. Select the background color scheme for the graph as desired.



6. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up Spectral Transmittance Analysis Parameters

This section presents the various analysis settings for the application. These settings are applied on subsequent acquisitions/re-analyses.

Note: *When you change the analysis setup parameters, the new settings are active as soon as you confirm your choice. The current trace is re-analyzed, and the analysis setup parameters will be applied to the global results and channel results for the following acquisitions.*


You can either set each parameter individually, or use parameters from the current trace and import them.

Setting Up the Instrument in Spectral Transmittance Mode

Setting Up Spectral Transmittance Analysis Parameters

To import the parameters from the current trace:


1. Make sure that you have a trace on-screen.
2. From the **Main Menu**, press **Analysis Setup**.



Setting Up the Instrument in Spectral Transmittance Mode

Setting Up Spectral Transmittance Analysis Parameters

3. From any tab, press **Import from Trace**.



4. Press **OK** to confirm the changes.

Setting Up the Instrument in Spectral Transmittance Mode

Setting Up Spectral Transmittance Analysis Parameters


Defining ST Analysis Settings

The global analysis parameters for spectral transmittance acquisitions affect the calculation of the results.

Note: When you change the analysis setup parameters, the new settings are active as soon as you confirm your choice. The current trace is re-analyzed, and the analysis setup parameters will be applied to the ST results for the following acquisitions.

To define ST analysis parameters:


1. From the **Main Menu**, press **Analysis Setup**.



Setting Up the Instrument in Spectral Transmittance Mode

Setting Up Spectral Transmittance Analysis Parameters


2. Select the **ST Analysis** tab.



Setting Up the Instrument in Spectral Transmittance Mode

Setting Up Spectral Transmittance Analysis Parameters

- Under **Global analysis parameters**, define the following parameters as needed:



- **Channel definition:** indicates the limit inside which the power values will be considered in the channel.

Centred on max peak: Channel is centered on the lowest insertion loss peak.

ITU Grid: Select the nearest ITU channel from the peak with lowest insertion loss.

CWDM: Select the nearest CWDM channel from the peak with lowest insertion loss.

Custom: Channel is centered on value specified by the user.


- **Nominal wavelength or frequency (nm or Thz):** indicates a single value that represent the channels center wavelength (in nm) or frequency (in THz). This field is editable only when Channel definition is selected as Custom.

Setting Up the Instrument in Spectral Transmittance Mode

Setting Up Spectral Transmittance Analysis Parameters

- Channel distance (GHz or nm): indicates distance between the channels. The value of channel distance will be set depending on the selection made for the channel definition option. The channel distance box will be enabled only when the channel center wavelength option is set to custom.
- Channel range (GHz or nm): indicates the limit inside which the power values will be considered in the channel. Integrated power is calculated on channel width.
- Bandwidth 1 at (dB): Set the power level used, relative to the channel peak power, to compute the bandwidth.
- Bandwidth 2 at (dB): Set the power level used, relative to the channel peak power, to compute the bandwidth.
- Input wavelength offset (nm): indicates the offset value applied on the input wavelength. This does not replace a calibration performed at EXFO, but it can help you temporarily sharpen the specifications if you have determined that, for example, your modules are used beyond the normal allowed use. Entering a value in THz is not possible. When an offset is applied, it is indicated at the bottom of the graph ($\lambda \leftrightarrow$).
- Input power offset (dB): indicates the offset value applied on the input power. This does not replace a calibration performed at EXFO, but it can help you achieve the specifications if you have determined that, for example, your modules are used beyond the normal allowed use. When an offset is applied, it is indicated at the bottom of the graph ($P \leftrightarrow$).

To edit the power offset value as a tap percentage, press the **Edit %** button.




Setting Up the Instrument in Spectral Transmittance Mode

Setting Up Spectral Transmittance Analysis Parameters

The percentage value entered in **Edit percentage** will be converted to a corresponding value in dB.

- Output wavelength offset (nm): indicates the offset value applied on the output wavelength. This does not replace a calibration performed at EXFO, but it can help you temporarily sharpen the specifications if you have determined that, for example, your modules are used beyond the normal allowed use. Entering a value in THz is not possible. When an offset is applied, it is indicated at the bottom of the graph ($\lambda \leftrightarrow$)
- Output power offset (dB): indicates the offset value applied on the output power. This does not replace a calibration performed at EXFO, but it can help you achieve the specifications if you have determined that, for example, your modules are used beyond the normal allowed use. When an offset is applied, it is indicated at the bottom of the graph (P \leftrightarrow).

To edit the power offset value as a tap percentage, press the **Edit %** button.



The percentage value entered in **Edit percentage** will be converted to a corresponding value in dB.

4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up Acquisition Parameters

Before performing your test, you must set the acquisition type and parameters.

There are three types of acquisitions in Spectral Transmittance mode: single, averaging and real-time.

- **Single:** Spectral measurement is performed once. The results are displayed according to this measurement.
- **Averaging:** Spectral measurements are performed based on the number of scans that you have entered for this parameter. The trace will be displayed after each acquisition and averaged with the previous traces.
- **Real-Time:** In real-time acquisition, spectral measurements are performed continuously until you press **Stop**. No averaging is done for spectral measurements. The graph and results are refreshed after each acquisition.

Before performing measurements on an optical spectrum, you must select the wavelength/frequency range to use. You can perform the scan on the full range, on spectral bands, or select a custom range.

Note: *The shorter the wavelength or frequency range, the faster the acquisition.*


Note: *The **Acquisition** tab is not available in offline mode.*

Setting Up the Instrument in Spectral Transmittance Mode


Setting Up Acquisition Parameters

To set parameters in the Acquisition tab:

1. From the main window, select the **Acquisition** tab.



2. Select the acquisition type.




Setting Up the Instrument in Spectral Transmittance Mode

Setting Up Acquisition Parameters


3. If you are performing an averaging type acquisition, enter the number of scans the unit will perform.

Note: You cannot modify the number of scans count value if you are performing a single or real-time acquisition.

4. Press **Input** or **Output** to specify which position to use to store the next acquisition.



5. Select the wavelength range for your acquisition.



You can select the wavelength range by entering the start and stop values or by selecting a range on the double slider.

To select the wavelength range using the double slider, move the left and right handles on the double slider or simply click on any band.

Note: You can select more than one adjoining ranges to include in your range, for example, S + C.

Setting Up the Instrument in Spectral Transmittance Mode

Setting Up Acquisition Parameters

The wavelength range covered within these bands of the spectra are listed below.

- O band (original): 1255 to 1365 nm
- E band (extended): 1355 to 1465 nm
- S band (short wavelengths): 1455 to 1535 nm
- C band (conventional “erbium window”): 1525 to 1570 nm
- L band (long wavelengths): 1560 to 1630 nm
- U band (ultralong wavelengths): 1620 to 1650 nm.

10 **Setting Up the Instrument in EDFA Mode**

Before performing a spectral analysis in the EDFA mode, you must set up your OSA module and the test application with the appropriate parameters, as explained in this chapter.


Select the EDFA test mode as explained in *Selecting a Test Mode* on page 20 before setting up the EDFA test parameters.

- The *preferences* are the result displayed in the graph and tables, as well as the job information and related comments saved with each file.
- The *analysis parameters* include the channel list details, and allows you to configure global analysis parameters.
- The *acquisition parameters* include the type of measurement you want to perform and the wavelength range.

See *Defining Preferences* on page 201, *Setting Up EDFA Analysis Parameters* on page 215 and *Setting Up Acquisition Parameters* on page 232 for more details.

Setting Up the Instrument in EDFA Mode

You can set up your unit in different manners depending on your testing needs.

- The preferred way is to use the complete analysis setup parameters and complete the information in all tables, as explained in *Setting Up EDFA Analysis Parameters* on page 215. This setup will be used for the next acquisition.
- The most efficient way to setup the instrument is to use one of the favorites configurations, uploading a pre-customized acquisition and analysis setup configuration. The operator in the field only has to press the  button, select the appropriate configuration and press **Start**. As an example, a pre-customized configuration could be: “32 channels DWDM 50GHz”; “Toronto-Montreal CWDM” or “Vendor ABC DWDM ROADM 40Gb”. This is explained in *Managing Favorites* on page 250.
- You can also import the setup from the current trace. This method will take the data and channel information from the current trace and apply them in the corresponding tabs. For more information, see *Setting Up EDFA Analysis Parameters* on page 215.

Defining Preferences

The preferences window allows you to set general information and comments on trace, set display parameters and customize the EDFA results table.


Note: Only the **Display** and **EDFA** tabs are available in offline mode.

Defining Trace Information

The trace information relates to the description of the job to be done, cable and job IDs, and any relevant information about what is being tested.

To enter general information:


1. From the **Main Menu**, press **Preferences**.



Setting Up the Instrument in EDFA Mode

Defining Preferences

2. Select the **General** tab.



The screenshot shows a software dialog box with a tabbed interface. The 'General' tab is selected and highlighted with a red circle. The dialog contains several input fields and a 'Clear' button. The fields are labeled as follows:

- Job ID: Your job
- Cable ID: 123_444
- Fiber ID: (empty)
- Customer: (empty)
- Company: Your company
- Operator: You
- Maintenance reason: (empty)


At the bottom of the dialog, there are 'OK' and 'Cancel' buttons, and a 'Clear' button is located above them. A help icon (?) is visible in the bottom-left corner.

3. Define the general parameters as needed.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Clear** to clear all the changes made in the **General** tab.

To enter link and location information:

1. From the **Main Menu**, press **Preferences**.



2. Select the **Information** tab.



Setting Up the Instrument in EDFA Mode

Defining Preferences

3. Under **System and link information**, define the following parameters as needed:

- Link ID prefix: prefix value for the link ID. You can enter any alphanumeric value.
- Starting value: suffix increment starting value for the link ID.

This value is incremented each time a new file is saved provided the **Auto Increment** option is selected.



IMPORTANT


When the Auto Increment option is not selected, while saving the trace file, you have to manually change the file name, else the application will overwrite the previously saved files every time you save a new trace.

- Orientation: orientation of the link.
 - System: information about the system under test.
4. Under **Location Information**, define the following parameters as needed:
 - Network element: type of network element.
 - Test point: where the test is performed on the link
 - Description: Enter the description of location if required.
 5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

To enter comments:


1. From the **Main Menu**, press **Preferences**.



Setting Up the Instrument in EDFA Mode

Defining Preferences

2. Select the **Comments** tab.



3. Enter your comments for the current trace.
4. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Clear** to clear all the changes made in the **Comments** tab.

Defining Display Parameters

The application allows you to set display settings for the acquisition trace. You can set the spectral unit for the trace and the results table. You can also select the label that should appear on the peaks of the trace.

To define display parameters:


1. From the **Main Menu**, press **Preferences**.




Setting Up the Instrument in EDFA Mode

Defining Preferences


2. Select the **Display** tab.



3. Select the spectral unit you want to work with, either nm or THz.




4. Select the label that will appear on the peaks in the graph, either the channel name, its number, or nothing.




Setting Up the Instrument in EDFA Mode

Defining Preferences

Note: The channel name and channel number cannot be shown at the same time.




Channel numbers




Defined channel names

5. Select whether you want to display the empty channels from the channel list in the **Results** tab.




6. Select whether you want to show the horizontal markers or the integrated power and the Δ trace in the marker toolbar.



Setting Up the Instrument in EDFA Mode

Defining Preferences

7. Select the background color scheme for the graph as desired.



8. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Restore Defaults** to remove all the changes and apply the default values.

Customizing EDFA Results Table

It is possible to select which results you would like to be displayed in the **Results** tab of your EDFA tests.

To customize the results table:


1. From the **Main Menu**, press **Preferences**.



Setting Up the Instrument in EDFA Mode

Defining Preferences

2. Select the **EDFA Results** tab.



3. Select which parameters you want to display in the **Results** tab from the list of available choices:
- Name: name of channel.
 - Center wavelength/frequency: spectral center-of-mass for the peak in that channel.
 - Input Signal Power: signal power for the selected channel (excludes noise).
 - Output Signal Power: signal power for the selected channel (excludes noise).
 - S %: current output power according to the measured output power ($\text{Output Signal Power} / [\text{Output Signal Power} + \text{PASE}]$).
 - PASE: power of the spontaneous emission amplified by EDFA.
 - PSSE: power of the spontaneous emission of the source.
 - Gain: gain ($\text{Output Signal Power} - \text{Input Signal Power}$) for the selected channel.

- Noise Figure: EDFA's noise figure measured for the selected channel.
 - Gain - Avg. Gain: selected channel gain minus the average of all channel gains.
4. Press the up or down arrows to change the order in which the columns will appear in the **Results** tab.
 5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up EDFA Analysis Parameters

This section presents the various analysis settings for the application, particularly the channel list and settings. You can set the channel list, channel parameters, manage favorite configurations and perform user calibration.

Note: *When you change the analysis setup parameters, the new settings are active as soon as you confirm your choice. The current trace is re-analyzed, and the analysis setup parameters will be applied to the global results and channel results for the following acquisitions.*


You can either set each parameter individually, or use parameters from the current trace and import them.

Setting Up the Instrument in EDFA Mode


Setting Up EDFA Analysis Parameters

To import the parameters from the current trace:

1. Make sure that you have a trace on-screen.
2. From the **Main Menu**, press **Analysis Setup**.



3. From any tab, press **Import from Trace**.



4. Press **OK** to confirm the changes.

Setting Up the Instrument in EDFA Mode

Setting Up EDFA Analysis Parameters

Defining General Settings

The general analysis parameters for EDFA acquisitions affect the calculation of the results. Any change you make to the settings affect future traces, or you can apply them to the active trace when reanalyzing it.




IMPORTANT


In the General tab, you can set the default channel parameters. Any channel found during an acquisition that is not defined in the channel list will be analyzed according to the default channel settings.

To define general settings:

1. From the Main Menu, press Analysis Setup.




2. Select the **General** tab.



Setting Up the Instrument in EDFA Mode

Setting Up EDFA Analysis Parameters

- Under **Default channel settings**, define the following parameters as needed:




- Clear the **Activate default channel** selection, to use the currently defined channel for analysis. This reduces the analysis time by eliminating the peak detection over the complete spectral range. The peaks outside the defined channel list will not be analyzed.

- Channel width (GHz or nm): indicates the limit inside which the power values will be considered in the channel.

For default channels, the channel width that sets the limits of the channel, should be the same as the channel distance or smaller (channel distance is defined while creating a channel list). If the channel width is not compatible with the channel spacing, either a single peak may be found for two distinct channels and two analysis would be performed and displayed for that peak, or, it is possible that two peaks may be found within the same channel and be considered as one multi-peak signal. With this result, you can use markers to find the spacing between adjacent channels or to find the channel width.

- Snap to ITU Grid: When selected, each detected peak will be defined by the nearest ITU channel. The ITU grid is based on the selected channel width.

4. Under **Global analysis parameters**, define the following parameters as needed:




Setting Up the Instrument in EDFA Mode

Setting Up EDFA Analysis Parameters

- Peak detection level (dBm): minimum power level from where the peak can be considered as a signal.
- RBW for OSNR (nm): indicates the resolution bandwidth selected for the OSNR calculation. This parameter is generally set to 0.1 nm to allow for a common basis of comparison between different OSAs having different effective resolutions. The instrument's RBW value is written below the graph. This parameter does not actually have an effect on the acquisition, but is only a normalization factor used to provide the OSNR value in a standardized manner.
- Input wavelength offset (nm): offset value applied on the input wavelength. This does not replace a calibration performed at EXFO, but it can help you temporarily sharpen the specifications if you have determined that, for example, your modules are used beyond the normal allowed. Entering a value in THz is not possible. When an offset is applied, it is indicated at the bottom of the graph ($\lambda \leftrightarrow$).
- Input power offset (dB): offset value applied on the input power. This does not replace a calibration performed at EXFO, but it can help you achieve the specifications if you have determined that, for example, your modules are used beyond the normal allowed. When an offset is applied, it is indicated at the bottom of the graph ($P \leftrightarrow$).

To edit the power offset value as a tap percentage, press the **Edit %** button.




The percentage value entered in **Edit percentage** will be converted to a corresponding equivalent value in dB.

Setting Up the Instrument in EDFA Mode

Setting Up EDFA Analysis Parameters

- **Output wavelength offset (nm):** offset value applied on the output wavelength. This does not replace a calibration performed at EXFO, but it can help you temporarily sharpen the specifications if you have determined that, for example, your modules are used beyond the normal allowed. Entering a value in THz is not possible. When an offset is applied, it is indicated at the bottom of the graph ($\lambda \leftrightarrow$).
- **Output power offset (dB):** offset value applied on the output power. This does not replace a calibration performed at EXFO, but it can help you achieve the specifications if you have determined that, for example, your modules are used beyond the normal allowed. When an offset is applied, it is indicated at the bottom of the graph ($P \leftrightarrow$).

To edit the power offset value as a tap percentage, press the **Edit %** button.



The percentage value entered in **Edit percentage** will be converted to a corresponding equivalent value in dB.

5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Restore Defaults** to remove all the changes and apply the default values.

Setting Up the Instrument in EDFA Mode

Setting Up EDFA Analysis Parameters


Managing Channels

Testing DWDM systems involves characterizing multiple signals in a link. The application allows you to define channels using a channel editor or quickly generate them from the current data. You can also rapidly create a list of equally spaced channels. Once a channel list is created, you can modify it as needed. You can edit the analysis parameters for one channel or multiple channels.

While creating the channel list, some channels may overlap. When the channel widths are specified in nm, two channels are considered to be overlapping when more than 1.2 GHz of frequency range is common between the two channels.

To add a channel list:


1. From the **Main Menu**, press **Analysis Setup**.




Setting Up the Instrument in EDFA Mode

Setting Up EDFA Analysis Parameters

2. Select the **Channels** tab.




3. By default, the channel list is empty. Press **Add Channels**.



Setting Up the Instrument in EDFA Mode

Setting Up EDFA Analysis Parameters

4. Enter values in the boxes as explained below:



- Start range (nm or THz): starting range of the channel list.
- Stop range (nm or THz): ending range of the channel list.
- Channel center wavelength/frequency: spectral center-of-mass for the peak in that channel.

Note: When using the custom channel center wavelength option, the first channel will be centered at the start range, and the list will be created using channel distance and channel width.

- Channel distance (nm or GHz): distance between the channels. The value of channel distance will be set depending on the selection made for the channel center wavelength option. The channel distance box will be enabled only when the channel center wavelength option is set to custom.
- Channel width (nm or GHz): limit inside which the power values will be considered in the channel. Integrated power is calculated on channel width.

- Name prefix: adds prefix to the channel names.
- Starting Value: sets the increment starting value for the channel name in the channel list.
- Increment value: sets the increment value for the channel name in the channel list.

5. Press **OK** to return to the **Channels** window, which now lists the added channels.

Note: *When new channels are added, the Use Default thresholds will be applied to the channel parameters.*

Note: *A warning message will be displayed if any channels are overlapping, but the analysis can still be performed on overlapping channels. If any duplicate channels are added, a confirmation message will be displayed to overwrite the existing channels with the duplicate channels.*

6. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Note: *The application displays a message if more than 1000 channels are added. You can exit the **Analysis Setup** window only after deleting the extra channels from the channel list. You can delete the channels manually as required.*

Setting Up the Instrument in EDFA Mode


Setting Up EDFA Analysis Parameters

To edit the parameters of a specific channel:

1. From the **Main Menu**, press **Analysis Setup**.



2. Select the Channels tab.




Setting Up the Instrument in EDFA Mode

Setting Up EDFA Analysis Parameters

3. Select the channel or channels to be modified in the channel list.

If you want the changes to be applied to all of your channels, press **Select All**. Channels can be selected one by one or all together. You can press **Unselect All** to clear all channel selections. To delete the selected channels, press **Delete**.


4. Press **Edit Selection**.



Setting Up the Instrument in EDFA Mode

Setting Up EDFA Analysis Parameters

5. Modify the settings as needed. For more information about the settings, see *Managing Channels on page 224*. If you leave a box empty, it will remain as it was before your changes.



6. Press **OK** to return to the **Channels** tab, which now contains the modified settings.
7. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Setting Up Acquisition Parameters

Before performing your test, you must set the acquisition type and parameters.

There are three types of acquisitions in EDFA mode: single, averaging and real-time.

- **Single:** Spectral measurement is performed once. The results are displayed according to this measurement.
- **Averaging:** Spectral measurements are performed based on the number of scans that you have entered for this parameter. The trace will be displayed after each acquisition and averaged with the previous traces.
- **Real-Time:** In real-time acquisition, spectral measurements are performed continuously until you press **Stop**. No averaging is done for spectral measurements. The graph and results are refreshed after each acquisition.

Before performing measurements on an optical spectrum, you must select the wavelength/frequency range to use. You can perform the scan on the full range, on spectral bands, or select a custom range.

Note: *The shorter the wavelength or frequency range, the faster the acquisition.*

Setting Up the Instrument in EDFA Mode


Setting Up Acquisition Parameters

To set parameters in the Acquisition tab:

1. From the main window, select the **Acquisition** tab.



2. Select the acquisition type.




Setting Up the Instrument in EDFA Mode

Setting Up Acquisition Parameters


3. If you are performing an averaging type acquisition, enter the number of scans the unit will perform.

Note: You cannot modify the number of scans count value if you are performing a single or real-time acquisition.

4. Press **Input** or **Output** to specify which position to use to store the next acquisition.



5. Select the wavelength range for your acquisition.



You can select the wavelength range by entering the start and stop values or by selecting a range on the double slider.

To select the wavelength range using the double slider, move the left and right handles on the double slider or simply click on any band.

Note: You can select more than one adjoining ranges to include in your range, for example, S + C.

The wavelength range covered within these bands of the spectra are listed below.

- O band (original): 1255 to 1365 nm
- E band (extended): 1355 to 1465 nm
- S band (short wavelengths): 1455 to 1535 nm
- C band (conventional “erbium window”): 1525 to 1570 nm
- L band (long wavelengths): 1560 to 1630 nm
- U band (ultralong wavelengths): 1620 to 1650 nm.


11 Starting a Measurement

Before starting a measurement you must select and configure a test mode. You will find the instructions to select a test mode in *Selecting a Test Mode* on page 20. For instructions on configuring various test modes, see their respective sections.

Note: *You cannot start a measurement in offline mode.*

To start the measurement:

From the main window, Press **Start**. The button will turn into a **Stop** button.



You are notified that the acquisition is in progress in the status bar.

When the acquisition is complete, the corresponding trace or traces, plus result data, trace information and pass-fail statuses, if activated, appear.

12 *Managing Files and Test Configurations*

Using the Discover Feature

The Discover feature allows you to start a measurement procedure to automatically build an analysis setup (scan range, channel list, analysis parameters, etc.) based on the signal being detected on the input port of the module.

Note: *The Discover features is available on the WDM and Drift test modes only.*

The procedure starts with a full range single scan (1250 nm to 1650 nm) to determine signal spectral range. It is followed by a second scan to establish the analysis parameters by locating the various peaks from the incoming signal.

When the discover process is successful, the application displays the results and graph for the detected channels and the newly discovered analysis parameters are applied automatically to the analysis setup.

Note: *If no signal is detected with the first scan, then the graph shows the full range scan and ends the discover procedure. The application analysis parameters remain unchanged.*

Managing Files and Test Configurations

Using the Discover Feature

Discover analysis parameters are established as follows:


- The acquisition spectral range is set at 5 nm before the first detected signal peak, and 5 nm after the last detected signal peak (respecting spectral range limits).
- A channel list is created based on detected signal peaks; default settings are applied for all channel parameters.
- The center wavelength of each channel is aligned with an ITU grid (200, 100, 50 or 25 GHz for DWDM).
- The channel width is determined using the overlap criteria; if two channels overlap by more than 0.001 nm or 0.001 GHz, then their widths are reduced to the lower width. If the width of two channels is at 25 GHz and they still overlap, then the width is not reduced and the application considers it as a multi-peak signal (like recent modulation formats for 10 Gb/s or 40 Gb/s) and sets the width of the channel to 50 GHz.

Note: *One of the limitations of using the Discover feature is that the channels are discovered based on the ITU-Grid. All detected peaks will be aligned with an ITU-channel; the channel width and distance are computed and fit in one of the ITU grids (25, 50, 100 or 200 GHz). If your channel is not based on the ITU grid, the results may not be correct. In this case, you can use the default channel definition or create a new channel list.*

To start an automatic setup measurement:

Note: You cannot do a setup measurement in offline mode.

From the **Main Menu**, press **Discover**. The **Start** button turns into a **Stop** button and the first scan of the discover starts.



Note: If you already have an active trace on screen that was modified, you will be prompted to save it. Any reference trace will be cleared.

You are notified that the discover acquisition is in progress in the status bar.

When the automatic setup measurement is complete, you can start using these newly detected parameters. Simply press **Start** to perform another measurement with the newly found settings.

Managing Measurement Files


The application allows you to manage the measurement files for all test modes. You can save files for future reference, open files to continue a test, or clear them to make room on your unit.


Note: You can also open files from one type of test into another type of test (for example, open a WDM trace while in EDFA test mode) for specific test needs, see Opening Files in Other Test Modes on page 246 for more information.

To save files:

1. From the **Main Menu**, Press **File**, and then press **Save As**.

OR

From the main window, press .



2. If desired, change the location and file name.
3. Press **Save** to save the trace, else press **Cancel** to exit the window.


Note: Once a trace is overwritten, you cannot access it anymore.

Note: You cannot save a reference trace.


To open a file:

1. From the **Main Menu**, Press **File**, and then press **Open**.

OR

From the main window, press .

2. If you had already acquired (but not saved) a trace, a warning window appears, asking you if you want to save the current trace. Press **Yes** to save the trace. Once the trace is saved, you can open a new trace. Press **No** to display the new trace without saving the previously acquired one. Press **Cancel** to return to the previous window.



Managing Files and Test Configurations

Managing Measurement Files

3. Scroll through the list and select a trace to open.
4. Select the trace type the file will be loaded into:
 - In WDM mode, two choices are available: Active Trace and Reference Trace.
 - In Spectral Transmittance and EDFA modes, when opening an OSA WDM file, two choices are available: Input Trace and Output Trace.

Note: *This option is not available in Drift, DFB and FP modes.*


If you are in WDM, Drift, EDFA or ST modes, you can select whether you want to also import the trace configuration and overwrite the current analysis setup and acquisition context at the same time that you open the file. The file type must be the same for the configuration importation to be valid. If you have selected to open a reference trace, the importation is done automatically.

Note: *If you open an active trace and a reference trace is already present, the current analysis setup will be applied to the active trace. If you open a reference trace its analysis setup will replace the current analysis setup.*

5. Press **Open** to open the file. The trace appears in the **Graph** tab. All the values in the main window will also be updated from the file.

To clear a file:

1. From the **Main Menu**, Press **File**.
2. Press **New**.



3. If you had already acquired (but not saved) a trace, a warning window appears, asking you if you want to save the current trace. Press **Yes** to save the trace. Once the trace is saved, you can make room for a new trace. Press **No** to create a new trace without saving the previously acquired one. Press **Cancel** to return to the previous window.

Note: In WDM mode, any reference trace will be cleared at this point.

Opening Files in Other Test Modes

Sometimes, you will need to open a file of a specific test mode while being in a different test mode. Depending on the type of file and the mode you selected, your unit will react differently.

Opening Other Test Mode Files in WDM Mode

Your application allows you to open different file types in WDM mode.

While loading a spectral transmittance (.osast) file, the application will re-analyze the newly imported data using the current WDM analysis setup.

While loading a legacy (.osw/.osm) file, the application will import only the raw trace data and acquisition conditions (date, acquisition type, averaging count and wavelength range). All results will be re-analyzed using the current WDM analysis setup.

While loading an EDFA (.osaedfa) file, the application will re-analyze the newly imported data using a temporary setup built from the retrieved channel list, retrieved default channel settings and blanks filled using the current WDM analysis setup.

While loading a spectral transmittance or EDFA file, the application imports trace data as follows:

- If an Input trace is present in the file, it is imported as the WDM reference trace.
- If an Output trace is present in the file, it is imported as the WDM active trace.

Opening Other Test Mode Files in DFB Mode

Your application allows you to open WDM file type in DFB mode.

While loading a WDM (.osawdm) file, the application will re-analyze the newly imported data using the DFB analysis setup and imports the following data from the selected trace:

- Raw trace data
- Trace information
- Trace identification

Opening Other Test Mode Files in FP Mode

Your application allows you to open WDM file type in FP mode.

While loading a WDM (.osawdm) file in the FP mode, the application will re-analyze the newly imported data using the FP analysis setup and imports the following data from the selected trace:

- Raw trace data
- Trace information
- Trace identification

Opening Other Test Mode Files in ST Mode

Your application allows you to open WDM file type in spectral transmittance mode.

While loading a WDM (.osawdm) file, the application behaves as if a new acquisition is requested. This means that the application does not change the modified state of the current measurement while loading a WDM file.

Before loading a WDM file, the application allows you to select in which trace you want to import the WDM file. Select **Input Trace**, or **Output Trace** as required. Once you have selected the file, the application imports the following data in the selected trace.

- Raw trace data
- Trace information
- Trace identification

Opening Other Test Mode Files in EDFA Mode

Your application allows you to open WDM file type in EDFA mode.

While loading a WDM (.osawdm) file, the application behaves as if a new acquisition is requested. This means that the application does not change the modified state of the current measurement while loading a WDM file.

Before loading a WDM file, the application allows you to select in which trace you want to import the WDM file. Select **Input Trace**, or **Output Trace** as required. Once you have selected the file, the application imports the following data in the selected trace.

- Raw trace data
- Trace information
- Trace identification

Managing Favorites


Favorites are configuration files that contain all of the parameters from the **Analysis Setup** tab and **Acquisition** tab. When you often use the same settings, you can save them as a favorite, then recall them for future acquisitions.


Note: The Favorites feature is available for the WDM, Drift and EDFA test modes.

To load a test configuration:


1. From the Main Menu, press **Analysis Setup**.

OR

From the main window, press .




2. Select the **Favorites** tab.



Managing Files and Test Configurations

Managing Favorites

3. To apply the settings from a favorite file to the current analysis setup, select a file from the favorites list and press **Apply Selection**. This button will be enabled only when a file is selected from the favorites list. When you press **Apply Selection**, the contents of the file are loaded in the other tabs of this window.




4. Press **OK** to proceed with the loaded configuration and close the window, or press **Cancel** to exit without saving.


Note: Pressing **OK** automatically starts the reanalysis process if a measurement file was already present.

To save a test configuration:

1. From the **Main Menu**, press **Analysis Setup**.

OR


From the main window, press .




Managing Files and Test Configurations

Managing Favorites

2. Select the **Favorites** tab.



3. To save an analysis setup to a file, press **Save As**. The default folder where the file will be saved is the Favorites folder. You should use this folder unless you want to transfer a copy on an external storing device such as a USB stick.





4. In the **Save As** window, enter a file name and press **Save**. The file will be added to the favorites list in the **Analysis Setup – Favorites** tab.
5. Press **Save** to save the configuration and close the window, or press **Cancel** to exit without saving.

To import a test configuration:

1. From the **Main Menu**, press **Analysis Setup**.

OR


From the main window, press .




Managing Files and Test Configurations

Managing Favorites


2. Select the **Favorites** tab.



3. Press **Import** to import an analysis setup from a file.



4. From the Import window, select the file you want to import and press **Open**. The file will be added to the favorites list in the **Analysis Setup – Favorites** tab.



5. Press **OK** to load the configuration and close the window, or press **Cancel** to exit without saving.

Note: To load this newly imported test configuration, you must select it from the favorites list and press **Apply Selection**.


Managing Files and Test Configurations


Managing Favorites

To delete a test configuration:


1. From the **Main Menu**, press **Analysis Setup**.

OR

From the main window, press .




2. Select the **Favorites** tab.



Managing Files and Test Configurations

Importing a Configuration from the Current Trace

3. To delete a configuration file from the favorites list, select it and press **Delete**. Press **Yes** to confirm your choice.



Importing a Configuration from the Current Trace

In WDM, Drift, EDFA and ST modes, you can import the analysis and channel configuration from the measurement file currently on-screen. See the corresponding test mode for details.

Using a Restore Point

When you modify the analysis setup and press **OK**, a restore point is created. This can be useful when you want to revert to the values you had prior to changing a test configuration.

You can keep up to three restore points during a working session, but they are cleared when you start a new session, or if you change the test mode.

13 *Managing Results*

Each test mode has its own results tabs, where you can view the trace details, channel results and global results for all measured channels.

You can use zoom options on the trace, configure markers to view the power values for specific wavelengths, and view trace information.

You can also manage trace files and generate reports for all test modes.

Note: *When a power result is flagged using an asterisk (*), it means that the detector is saturated. When the optical power on the detector is too high, the detector gets saturated and the returned value is probably incorrect.*

Note: *When an OSNR or a noise result is flagged using a question mark (?), it means that the quality of the result is insufficient to make a valid calculation. This indication can be produced when analyzing an InBand/i-InBand measurement, or when computing noise through polynomial fit . This indication can arise in the following situations:*

- InBand/i-InBand averaging was made using a very few scans (1 or 2 for example). Usually produced when the operator presses the **Stop** button before the end of the InBand/i-InBand acquisition.
- The data in the measured channel is subjected to fast polarization scrambling, or is a polarization multiplexed signal.
- One channel might have a misfit with the current state of the polarization scrambler inside the module. This can be corrected by moving the fiber at the entrance of the module.
- The polarization scrambler inside the module could be defective. If you suspect this option please contact EXFO technical support for a more complete diagnosis.
- Polynomial fit coefficient correlation is questionable.

Managing Results


Managing WDM Test Results

Managing WDM Test Results

The application allows you to view and manage your WDM test results. You can view the graph of your acquisition, results for a single channel, global results and information about the trace.


Graph Tab

The **Graph** tab allows you to view the spectrum of the active and reference traces. This graph represents the optical power against wavelength or frequency.



When the acquisition is taken (see *Starting a Measurement* on page 237 for details on how to perform a test), the active trace will be displayed in the tab with information along the following axis values:

- X axis: wavelength in nm or frequency in THz.
- Y axis: optical power expressed in dBm, as measured in the optical resolution bandwidth (RBW) of the OSA. This reference RBW is shown at the bottom of the graph.



If the current active trace was previously saved, the application will display the file name of the current trace in the status bar.

The graph will display peak indicators for all the channels found by the application with a red vertical line over the peaks to indicate the peak position.


A blue horizontal bar (■) will be displayed on the top of a channel if it does not overlap with another channel. If the channel overlaps with another channel, the horizontal bar will be yellow (■).

Managing Results


Managing WDM Test Results

The selected peak indicator, a small red inverted triangle (▼) points down at the top of the currently selected channel peak. In the graph zone, you can change the selected peak by clicking inside the peak limits of the desired channel. Peak selection in the graph is synchronized with the channel selection in lower tab results list; changing the selection in the graph modifies the selection in the list and vice-versa.


Note: *This is valid only for channels in the list for which a signal is detected. If you select a channel that has no signal, no peak is selected in the graph.*



The noise level for a channel is indicated by a dotted line under the selected peak. The width of the noise level indicator is set according to the current Noise for OSNR setting. The width of the noise level indicator depends on the noise associated with the OSNR setting (from the largest to the narrowest): IEC, InB, InB nf and fit.



A dotted line across the full spectral width corresponds to the peak detection level indicator. This line indicates the minimum power level (dBm) from where a peak can be considered as a valid signal.




A peak detection level cursor is available in the graph when the **Results** tab is selected. The cursor is positioned along the Y-axis in accordance with the application's peak detection level global analysis parameter.

Managing Results

Managing WDM Test Results

You can move the cursor to modify the peak detection level for the current measurement. Each time the cursor is moved, the trace(s) is/are fully analyzed again using the application analysis setup.



Note: If you select another tab than **Results**, the cursor disappears, but you can still see the peak detection level indicator line.

Note: If there is a reference trace, it appears in gray in the graph.

Note: For more information on these, see [Managing Markers on page 311](#) and [Using Zoom Controls on page 309](#).

Results Tab

In the **Results** tab, each channel will be represented for both the active and reference traces, with the delta between both results. Only the results for the channels within the scan range will be analyzed. The pass (✔)/fail (✘) verdict for thresholds are also displayed; if the verdict is fail for any parameter, its value will appear in red.

To view results:

From the main window, select the **Results** tab.

	Ch. #	λ (nm)	Power (dBm)	OSNR (dB)	Noise (dBm)	BW 3.00 dB (nm)	BW 20.00 dB (nm)
Active	1	1535.033	(i)-9.88	20.90	(InB nF)-30.78	0.065	0.44
Ref.			-	-	-	-	-
Δ			-	-	-	-	-
Active	2	1535.832	(i)-6.04	36.15	(InB nF)-42.19	0.067	0.22
Ref.			-	-	-	-	-
Δ			-	-	-	-	-

Note: For details on filtering displayed channel results, see Defining Display Parameters on page 50

For details on each result type, see Customizing WDM Results Table on page 57.

Managing Results


Managing WDM Test Results

Channel Results Tab

The application allows you to view the complete information about the parameters measured for the selected channel. This is also where the pass/fail verdict for thresholds are displayed. If the verdict is fail for any parameter, its value will appear in red. If the verdict is pass, its value will appear in green.

To view channel results:

1. From the main window, select **Channel Results** tab.



2. Select a row from the **Results** tab to view the results for this channel.

The screenshot shows the software interface with the following data:

Channel Results Table:

Channel number	3
Channel name	C_003
Channel Results	
Center wavelength	1534.262 nm
Wavelength deviation	0.000 nm
Signal power	(i)-17.69 dBm
Noise	(InB nf)-49.00 dBm
OSNR	31.30 dB
Bandwidth 3.00 dB	0.066 nm
Bandwidth 20.00 dB	0.198 nm
ENBW	0.065 nm
Channel Analysis Parameters	
Channel center	1534.262 nm
Channel width	50.0 GHz
Signal power calculation	Integrated signal

Results Table:

Ch. #	λ (nm)	Power (dBm)	OSNR (dB)	Noise (dBm)	BW 3.00 dB (nm)	BW 20.00 dB (nm)
1	1531.117	(i)-15.72	32.52	(InB nf)-48.23	0.066	0.203
2	1532.664	(i)-18.44	30.32	(InB nf)-48.76	0.066	0.199
3	1534.262	(i)-17.69	31.30	(InB nf)-49.00	0.066	0.198
4	1535.818	(i)-18.33	30.61	(InB nf)-48.94	0.066	0.199
5	1537.002	(i)-21.54	25.21	(InB nf)-46.75	0.060	0.172
6	1537.402	(i)-23.22	23.41	(InB nf)-46.62	0.063	0.186
7	1537.797	(i)-20.91	25.77	(InB nf)-46.68	0.060	0.170

Note: Values displayed in the **Channel Result** tabs are those of the active trace only.

Note: For details on each result type, see Customizing WDM Results Table on page 57 and Defining General Settings on page 62.

Note: The wavelength/frequency deviation is the difference between the channel center wavelength/frequency and the measured signal center wavelength/frequency.

Managing Results


Managing WDM Test Results

Global Results Tab

The application allows you to view the global results of the current measurement. The pass/fail verdict for thresholds are displayed in the **Global Results** tab. If the verdict is fail for any parameter, its value appears in red. If the verdict is pass, its value appears in green.

To view global results:

From the main window, select the **Global Results** tab.



Results and analysis parameters global to all channels will be displayed. For more information on each item, see *Defining Global Thresholds* on page 70 and *Defining General Settings* on page 62.

In addition, you can view the global pass/fail status, provided the thresholds are activated in the **Global Result Thresholds** tab in the **Analysis Setup** window. If the thresholds are enabled, the **Pass/Fail status** pane will display a Pass or Fail status based on the global results, or **Not Active** if the thresholds are disabled.

Note: Values displayed in the **Global Results** tab are indicated for the active trace only.

WDM Investigator Tab

The WDM Investigator tab presents information allowing you to do massive network prevention and maintenance. With the WDM Investigator dashboard, an OSA can identify several types of impairments on a per-channel basis, which gives visibility into a WDM network. In addition, the WDM Investigator dashboard provides useful information on the channel characteristics.

Note: *If your measurement file contains diagnostic information, the latter will be stored in the file when you save it. It will be possible to view the diagnostic information later with the OSA application (the WDM Investigator (Inv) option is not required to view the stored file). You can also view the same information with the offline application*

Channel diagnostics and the WDM Investigator tab are only available for the active trace, if the two conditions below are met:


- The measurement under analysis was performed on an OSA module onto which the WDM Investigator (Inv) software option is activated.
- Diagnostics are computed only for channels analyzed with the i-InBand noise for OSNR.

Managing Results

Managing WDM Test Results

To view the WDM Investigator diagnostics:

From the main window, select the **WDM Investigator** tab.



As you change the channel selection in the WDM Investigator tab, the selected row in the Results tab list will move accordingly to indicate the corresponding channel analysis results.

The WDM Investigator diagnostics are divided into two types: channel characteristics (informative) and impairments (qualitative). Both the channel characteristics and the impairment identification help to pinpoint the exact failure affecting a channel, which reduce test time and help prevent future failures.

There are two channel characteristic types:




- **Pol-Mux signal:** This specific kind of channel characteristic determines if the signal is polarization multiplexed. Pol-Mux signals appear unpolarized (minimal polarization extinction) at the end of an i-InBand acquisition.

Note: When a signal is identified as Pol-Mux, no further diagnostics are provided.

Note: This information is available for polarized signals only.

- Carved noise: When the ASE noise is filtered so that the noise level affecting the peak at the center is higher than the noise level at either channel edge, this usually indicates the presence of filters/ROADMs on the link.

Four levels of information are given for channel characteristics diagnostics.

Symbol	Meaning
	Not present
	Present
	Inconclusive
No symbol (blank)	Not analyzed (empty channel)

Impairment diagnostics check for the presence of several types of impairments and give an assessment of their severity. There are four impairment types:

- PMD Pulse Spreading: This impairment shows the presence of Polarization Mode Dispersion (PMD) in a channel. When PMD is present on the path of the signal, depending on the polarization axis of the signal injected, the signal may suffer from pulse spreading which, in turn, leads to polarization dependent spectral deformations. These deformations can be analyzed to determine how much polarization pulse broadening the signal has experienced during the measurement.





Managing Results

Managing WDM Test Results

- **Interchannel Crosstalk:** In densely-filled channel plans, neighboring channels may have a non-negligible portion of their spectrum that extends within the channel bandpass of a given signal.
- **Non Linear Depolarization:** Fast changing power levels in multichannel systems (10 G and 40 G) may induced local polarization dependent changes in the refraction index of the fiber. This, sometimes, leads to inter-channel nonlinear effects (for example cross-phase modulation) which, in turn, lead to partial depolarization of neighboring channels.
- **Carrier leakage:** In a phase-modulated transmission, a CW carrier wave is modulated using external modulators which are generally polarization dependent. When the CW source polarization axis is not optimally aligned with the modulator, a portion of the CW signal passes through unmodulated and gets transmitted as such along the path. When this CW residual signal is present, it may be detected as carrier leakage using advanced polarization analysis to provide a useful diagnostic.

The symbols that are used to illustrate the diagnostics are the same, regardless of the type of impairment. The global diagnostic status is shown in the status bar at the bottom of the window according to the severity displayed in the table below. The most severe status takes precedence over the others for all tested channels.

Five statuses are provided for impairments diagnostics. The symbols are presented from the most severe to the least severe.

Symbol	Meaning
	Risk
	Warning
	Inconclusive
	OK
No symbol (blank)	Not analyzed (empty channel)

Managing Results


Managing Drift Test Results

Managing Drift Test Results

The application allows you to view and manage your drift test results. You can view the dashboard, channel graph and WDM graph of your drift acquisition, channel history results for a single channel and information about the trace.

Dashboard Tab

The dashboard allows you to view at-a-glance the pass/fail status of each parameter for each channel that is measured during a drift measurement. When there is no measurement, the dashboard is blank.



You can select a channel directly from the dashboard or from the **Channel History** tab. For each channel, the dashboard displays the pass/fail status for each of the following parameters:

- Central wavelength/frequency
- Signal power
- OSNR

Both the current pass/fail status (last completed acquisition) and the historical pass/fail status are displayed in the dashboard. The historical pass/fail status will be set to Fail as soon as one occurrence of fail has occurred in the past or in the current acquisition.

The screenshot shows a dashboard with tabs for Dashboard, Channel Graph, WDM Graph, and Channel Results. The Channel Results tab is active, displaying a grid of pass/fail status for three parameters: $\Delta\lambda$, ΔP , and $\Delta OSNR$. Each parameter has two columns: Historical (H) and Current (C). The status is indicated by green circles (PASS) or red circles (FAIL). A red box highlights the Historical and Current columns. Below the grid, a list of channel numbers is shown, with the first one, 1546.877, selected. A table at the bottom shows the Channel History for the selected channel, including Reference, Current Drift, Maximum, T Max., Minimum, and T Min. values for λ , Power, and OSNR.

Item	Reference	Current Drift	Maximum	T Max.	Minimum	T Min.
λ	1546.877 nm	0.054 nm	1546.931 nm	04:59:00	1546.877 nm	00:00:00
Power	-41.97 dBm	-0.41 dB	-41.96 dBm	00:02:00	-42.39 dBm	04:57:00
OSNR	23.23 dB	-0.80 dB	24.12 dB	04:09:00	22.07 dB	00:16:00

Managing Results

Managing Drift Test Results

The dashboard shows a global status (all channels) for each parameter. This global status is set to Fail if at least one channel has a failed historical status for that given parameter, otherwise the global status is set to Pass.

Dashboard Channel Graph WDM Graph Channel Results

Historical : H Current : C

$\Delta\lambda$ H PASS

ΔP H PASS

$\Delta OSNR$ H PASS

Ref. empty channel count: 0

Item	Reference	Current	Drift	Maximum	T Max.	Minimum	T Min.
λ	1546.877 nm	0.054 nm	1546.931 nm	04:59:00	1546.877 nm	00:00:00	
Power	-41.97 dBm	-0.41 dB	-41.96 dBm	00:02:00	-42.39 dBm	04:57:00	
OSNR	23.23 dB	-0.80 dB	24.12 dB	04:09:00	22.07 dB	00:16:00	

Acquisition Drift Settings Channel History Trace Info

C_001

The dashboard displays a channel status (all parameters) for a given channel. This channel status is set to Fail as soon as one of the parameters has a failed historical status for that given channel, otherwise the channel status is set to Pass.

The screenshot shows a software interface with the following components:

- Navigation Tabs:** Dashboard, Channel Graph, WDM Graph, Channel Results (selected).
- Channel Results Grid:**
 - Historical: H, Current: C
 - Parameters: $\Delta\lambda$, ΔP , $\Delta OSNR$
 - Status: PASS (indicated by green checkmarks)
- Reference Values:** A list of values highlighted in a red box: 1546.877, 1547.989, 1549.109, 1550.243, 1551.367, 1552.487, 1553.619, 1554.761, 1555.893, 1557.017, 1558.157, 1559.309, 1560.445, 1561.581, 1562.733, 1563.881, 1565.028, 1566.172, 1567.336, 1568.496.
- Channel History Table:**

Item	Reference	Current Drift	Maximum	T Max.	Minimum	T Min.
λ	1546.877 nm	0.054 nm	1546.931 nm	04:59:00	1546.877 nm	00:00:00
Power	-41.97 dBm	-0.41 dB	-41.96 dBm	00:02:00	-42.39 dBm	04:57:00
OSNR	23.23 dB	-0.80 dB	24.12 dB	04:09:00	22.07 dB	00:16:00
- Right Panel:** Start button, Open/Save/Fav. icons, Main Menu/File, Back/Home, New, Open..., Save As..., Report..., About.
- Bottom Panel:** Acquisition, Drift Settings, Channel History (selected), Trace Info. A dropdown menu shows 'C_001'.


Managing Results

Managing Drift Test Results

Channel Graph Tab

The **Channel Graph** tab displays three different graphs for the selected channel. You can select which graphs you want to display from the **Drift Results** tab in the **Preferences** Window. The three graphs are X-Y plots of:


- Spectral position (center of mass of wavelength or frequency) of the channel over time
- Signal power of the channel over time
- OSNR of the channel over time



Channel History Tab


The channel history table shows channel results for the active trace. The result is displayed for the selected channel only. The pass/fail verdict for thresholds are also displayed in the results table. If the verdict is fail for any parameter, its value will appear in red.

The application displays the progress of the measurement in the status bar, while the acquisition is taken. The Elapsed time and Expected duration for the measurement to stop is displayed in the **Channel History** tab.



To view channel history results:

From the main window, select the **Channel History** tab.



Results for the following parameters related to the selected channel are displayed in the **Channel History** table:

- Spectral position (center of mass of wavelength or frequency) of the channel against time (nm or THz)
- Signal power of the channel against time (dBm)
- OSNR of the channel against time (dB)


Managing Results

Managing Drift Test Results

For each of the above parameters, the following results are displayed:


- Reference: channel reference values for the current drift acquired during the initial acquisition.
- Current Drift: current drift values, that is, the current deviation from the channel's reference for the drift's latest acquisition.
- Maximum: maximum values reached during the drift.
- T Max.: time of the drift at which the channel was at its maximum value. Displayed time is relative to the time at the start of the drift measurement.
- Minimum: minimum values reached during the drift.
- T Min.: time of the drift at which the channel was at its minimum value. Displayed time is relative to the time at the start of the drift measurement.

A small red marker (▼) will point down at the peak in the **WDM Graph** tab when you select a channel in the **Channel History** tab. The red marker will move accordingly to indicate the corresponding peak on the graph, with a focus on the selected channel.



WDM Graph Tab

The **WDM Graph** tab allows you to view the spectrum of the active trace for the last WDM acquisition in your drift measurement. This graph represents the optical power versus wavelength or frequency.




Managing Results

Managing Drift Test Results

When the acquisition is taken (see *Starting a Measurement* on page 237 for details on how to perform a test), the active trace will be displayed in the tab with information along the following axis values:

- X axis: wavelength in nm or frequency in THz.
- Y axis: optical power expressed in dBm, as measured in the optical resolution bandwidth (RBW) of the OSA. This reference RBW is shown at the bottom of the graph.



The graph will display peak indicators for all the channels found by the application with a red vertical line over the peaks to indicate the peak position.


A blue horizontal bar (■) will be displayed on the top of a channel if it does not overlap with another channel. If the channel overlaps with another channel, the horizontal bar will be yellow (■).

Channel Results Tab

When you select a channel in the **Channel History** tab, the **Channel Results** tab will show complete information about the parameters measured for the selected channel. The pass/fail verdict for thresholds are also displayed in the **Channel Results** tab. If the verdict is fail for any parameter, its value appears in red. If the verdict is pass, its value appears in green.

To view channel results:


1. From the main window, select **Channel Results** tab.



Managing Results

Managing Drift Test Results

2. Select a channel from the **Channel History** tab to view the channel results for the selected channel.



Item	Reference	Current Drift	Maximum	T. Max.	Minimum	T. Min.
λ	1546.877 nm	0.054 nm	1546.931 nm	04:59:00	1546.877 nm	00:00:00
Power	-41.97 dBm	-0.41 dB	-41.96 dBm	00:02:00	-42.39 dBm	04:57:00
OSNR	23.23 dB	-0.80 dB	24.12 dB	04:09:00	22.07 dB	00:16:00


Note: For details on each item, see Customizing WDM Results Table on page 57 and Defining General Settings on page 62.

Managing DFB Test Results

The application allows you to view and manage your DFB test results. You can view the graph and results for your DFB laser source.

DFB Graph Tab

The **DFB Graph** tab allows you to view the spectrum of a DFB laser source. This graph represents the optical power against wavelength or frequency.




Managing Results

Managing DFB Test Results

When the acquisition is taken (see *Starting a Measurement* on page 237 for details on how to perform a test), the active trace will be displayed in the tab with information along the following axis values:

- X axis: wavelength in nm or frequency in THz.
- Y axis: optical power expressed in dBm, as measured in the optical resolution bandwidth (RBW) of the OSA. This reference RBW is shown at the bottom of the graph.




If the current trace was previously saved, the graph will display the file name of the current trace in the status bar.

Results Tab

You can view the analysis of the DFB laser source from the **Results** tab.

To view results:

From the main window, select the **Results** tab.



Acquisition		Results	Trace Info.	
Center wavelength:	1530.331 nm	Worst case SMSR:	51.45 dB	
Peak power:	5.15 dBm	Worst case SMSR position:	1530.895 nm	
Bandwidth at 3.00 dB:	0.031 nm	Left stopband:	0.443 nm	
Bandwidth at 20.00 dB:	-	Right stopband:	0.564 nm	
Left SMSR:	59.36 dB	Central offset:	-0.060 nm	
Right SMSR:	51.45 dB	Fabry-Perot mode spacing:	0.675 nm	

The following information related to the DFB measurement is displayed in the **Results** table:

- Center wavelength/frequency: spectral center-of-mass for the peak.
- Peak power (dBm): peak signal power.
- Bandwidth 3.00 dB: bandwidth measured by taking the width of a signal at 50 % linear power of the peak or -3 dB from the peak.
- Bandwidth 20.00 dB: bandwidth measured by taking the width of a signal at 1 % linear power of the peak or -20 dB from the peak.
- Left SMSR: Left side-mode suppression ratio. It is the power difference between the main mode and the most powerful outstanding side-mode on the left.
- Right SMSR: Right side-mode suppression ratio. It is the power difference between the main mode and the most powerful outstanding side-mode on the right.

Managing Results

Managing DFB Test Results


- Worst case SMSR: power difference between the main mode and the side-mode with the highest power.
- Worst case SMSR position: spectral position of the worst SMSR.
- Left stopband: spectral position difference between the main mode and the closest side-mode on the left.
- Right stopband: spectral position difference between the main mode and the closest side-mode on the right.
- Central offset: spectral position of the main mode minus the mean of the spectral positions of the first adjacent left and right side-modes.
- Fabry-Perot mode spacing: average estimated spectral spacing between adjacent Fabry-Perot modes of the DFB.

Managing FP Test Results

The application allows you to view and manage your FP test results. You can view the graph and results for your FP laser source.

FP Graph Tab

The **FP Graph** tab allows you to view the spectrum of a FP laser source. This graph represents the optical power against wavelength or frequency.




Managing Results

Managing FP Test Results

When the acquisition is taken (see *Starting a Measurement* on page 237 for details on how to perform a test), the active trace will be displayed in the tab with information along the following axis values:

- X axis: wavelength in nm or frequency in THz.
- Y axis: optical power expressed in dBm, as measured in the optical resolution bandwidth (RBW) of the OSA. This reference RBW is shown at the bottom of the graph.




If the current trace was previously saved, the graph will display the file name of the current trace in the status bar.

Results Tab

You can view the analysis of the FP laser source from the **Results** tab.

To view results:

From the main window, select the **Results** tab.



Acquisition		Results		Trace Info.	
Center wavelength:	1549.177 nm	Peak mode power:	-14.03 dBm		
RMS width:	3.563 nm	Peak mode wavelength:	1552.641 nm		
FWHM:	3.264 nm	MTSM at 10.00 dB:	7.651 nm		
Gaussian fit error factor:	0.16	Fit width at 3.00 dB:	8.375 nm		
Total power:	-1.20 dBm	Fit width at 20.00 dB:	21.624 nm		
Power (detected modes):	-1.26 dBm	Mode spacing:	1.749 nm		

The following information related to the FP measurement is displayed in the **Results** table:

- Center wavelength/frequency: spectral center-of-mass for the peak.
- RMS width: indicates the second moment of the spectral distribution.
- FWHM: indicates the full width at the half-maximum position.
- Gaussian fit error factor: indicates the normalized RMS error factor in the Gaussian fit.
- Total power (dBm): indicates the integrated power of the acquisition window.
- Power (detected modes) (dBm): indicates the integrated power from the starting point of the first mode to the ending point of the last mode.
- Peak mode power (dBm): indicates the power of the peak mode of the Fabry-Perot laser.

Managing Results

Managing FP Test Results


- Peak mode wavelength/frequency: indicates the wavelength/frequency of the peak mode of the Fabry-Perot laser.
- MTSM at 10.00 dB: indicates the maximum wavelength difference between the peak power mode and the last mode with amplitude that is one tenth (10 dB down) of the peak mode amplitude.
- Fit width at 3.00 dB: indicates the spectral width of the Gaussian fit at 3 dB.
- Fit width at 20.00 dB: indicates the spectral width of the Gaussian fit at 20 dB.
- Mode spacing: average estimated spectral spacing between adjacent Fabry-Perot modes of the FP.

Managing Spectral Transmittance Test Results

The application allows you to view and manage your spectral transmittance test results. You can view the graph of your acquisition, results for a single channel, global results and information about the trace.

ST Graph Tab

The **ST Graph** tab allows you to view the spectrum of the input trace, the output trace and the calculated ST trace. This graph represents the optical power against wavelength or frequency.




Managing Results

Managing Spectral Transmittance Test Results

When the acquisition is taken (see *Starting a Measurement* on page 237 for details on how to perform a test), the active trace will be displayed in the tab with information along the following axis values:

- X axis: wavelength in nm or frequency in THz.
- Y axis: optical power expressed in dBm, as measured in the optical resolution bandwidth (RBW) of the OSA. This reference RBW is shown at the bottom of the graph.




If the current trace was previously saved, the graph will display the file name of the current trace in the status bar.

Results Tab

The results table shows the spectral transmittance results for the active trace. Results for only the channels within the scan range will be displayed.

To view results:

From the main window, select the **Results** tab.



The following results related to the channels are displayed:

- Nominal center wavelength or frequency: single value representing the channels center wavelength (in nm) or frequency (in THz).
- Offset to nominal wavelength or frequency: offset value applied to the nominal wavelength (nm) or frequency (THz).
- Insertion loss min: minimum difference between a reference power level and the measured power level (in dB).
- Insertion loss max: maximum difference between a reference power level and the measured power level (in dB).
- Bandwidth x at (dB): bandwidth measured by taking the width of a signal at x dB from the peak.
- Bandwidth y at (dB): bandwidth measured by taking the width of a signal at y dB from the peak.
- Adjacent channel isolation: isolation (in dB) taken at the channel distance on the left or right of the nominal wavelength. The worst value between the left and right isolation is kept.

Managing Results


Managing Spectral Transmittance Test Results

ST Results Tab

The **ST Results** tab will show complete information about the spectral transmittance parameters and the global analysis parameters.

To view ST results:

From the main window, select **ST Results** tab.



Note: For details on each item, see Results Tab on page 297 and Defining ST Analysis Settings on page 190.


Swapping Spectral Transmittance Traces

The Swap Trace feature allows you to swap spectral transmittance input and output traces. With this feature, the input trace is replaced with the output trace and vice versa. All results are recalculated.

Note: *The swap trace feature will not be available if there are no traces in the application.*

To swap spectral transmittance traces:

From the **Main Menu**, press **Swap Traces**.



All the parameters in the application will be updated according to the modified traces.

Managing Results


Managing EDFA Test Results

Managing EDFA Test Results

The application allows you to view and manage your EDFA test results. You can view the graph of your acquisition, results for a single channel, global results and information about the trace.


EDFA Graph Tab

The **EDFA Graph** tab allows you to view the spectrum of the input trace and the output trace. This graph represents the optical power against wavelength or frequency.



When the acquisition is taken (see *Starting a Measurement* on page 237 for details on how to perform a test), the trace will be displayed in the **EDFA Graph** tab with information along the following axis values:

- X axis: wavelength in nm or frequency in THz
- Y axis: optical power expressed in dBm, as measured in the optical resolution bandwidth (RBW) of the OSA. This reference RBW is shown in the graph.



If the current trace was previously saved, the graph will display the file name of the current trace in the status bar.

The graph will display peak indicators for all the channels found by the application with a red vertical line over the peaks to indicate the peak position.

A blue horizontal bar (■) will be displayed on the top of a channel if it does not overlap with another channel. If the channel overlaps with another channel, the horizontal bar will be yellow (■).

Managing Results

Managing EDFA Test Results

Results Tab

The results table shows channel results for both the input or output traces. The results for only the channels within the scan range will be displayed.


To view results:

From the main window, select the **Results** tab.

Ch. #	λ (nm)	Input Signal Power (dBm)	Output Signal Power (dBm)	S%	PASE (dBm)	PSSE (dBm)
1	1539.747	(p)-7.75	(p)6.79	99.97	-28.43	-49.16
2	1541.395	(p)-7.18	(p)8.24	99.98	-27.79	-48.80
3	1545.509	(p)-43.75	(p)-26.27	50.07	-26.28	-47.93
4	1546.921	(p)-7.12	(p)10.73	99.98	-26.07	-47.77

For information on each item, see *Customizing EDFA Results Table* on page 213.

A small red marker (▼) will point down at the peak in the **EDFA Graph** tab when you select a row in the **Results** tab. The red marker will move accordingly to indicate the corresponding peak on the graph, with a focus on the selected channel.




Channel Results Tab


When you select a row from the **Results** tab, the **Channel Results** tab will show complete information about the parameters measured for the selected channel.

To view channel results:

1. From the main window, select **Channel Results** tab.



2. Select a row from the **Results** tab to view the channel results for the selected channel.




For details on each item, see *Customizing EDFA Results Table* on page 213.

Global Results Tab

The application allows you to view the global results of the current measurement.

To view global results:

From the main window, select the **Global Results** tab.



Global Results	
Input average signal power	-8.59 dBm
Input signal power flatness	36.63 dB
Output average signal power	7.65 dBm
Output signal power flatness	37.00 dB
Gain flatness	3.30 dB
Average gain	16.54 dB
Gain slope (tilt)	0.47 dB/nm
Global Analysis Parameters	
Peak detection level	-45.00 dBm
RBW for OSNR	0.100 nm
Input wavelength offset	0.000 nm
Input power offset	0.00 dB
Output wavelength offset	0.000 nm
Output power offset	0.00 dB

Results for the following parameters for all the channels will be displayed:

- Input average signal power: sum of the signal powers of all the peaks detected in the current acquisition, divided by the total number of peaks.
- Input signal power flatness: difference between the maximum and minimum signal power values of the detected peaks, in dB.
- Output average signal power: sum of the signal powers of all the peaks detected in the current acquisition, divided by the total number of peaks.
- Output signal power flatness: difference between the maximum and minimum signal power values of the detected peaks, in dB.
- Gain flatness: difference between the maximum and minimum gain values of the detected channels, in dB.

- Average gain: sum of the gain of all detected channels in the current measurement, divided by the total number of channels.
- Gain slope (tilt): slope of the linear fit on the gain values of the detected channels.

Swapping EDFA Traces

The Swap Trace feature allows you to swap EDFA input and output traces. With this feature, the input trace is replaced with the output trace and vice versa. All results are recalculated.

Note: *Swap Trace feature will not be available if there are no traces in the application.*

To swap EDFA traces:

From the **Main Menu**, press **Swap Traces**.



All the parameters in the application will be updated according to the modified traces.

Managing Results


Adjusting the Display Size


Adjusting the Display Size


Your application allows you to toggle the view of your main window. You can change the view of the upper and lower tabs from the normal view to 100 % upper tabs or 100 % lower tabs view.

To adjust the display size:

For 100 % upper tabs view, press .



For 100 % lower tabs view, press .



The screenshot shows a software interface with a table of acquisition results and a sidebar menu. The table has the following columns: Ch. #, λ (nm), Power (dBm), OSNR (dB), Noise (dBm), BW 3.00 dB (nm), BW 20.00 dB (nm), and $\Delta\lambda$ (nm). The sidebar menu includes buttons for Start, Open, Save, Fav., Main Menu, File, Discover, Preferences..., Analysis Setup..., and Mode.

Ch. #	λ (nm)	Power (dBm)	OSNR (dB)	Noise (dBm)	BW 3.00 dB (nm)	BW 20.00 dB (nm)	$\Delta\lambda$ (nm)
1	1529.579	(-)-4.50	20.53	(InB nf)-25.02	0.057	0.187	0.000
2	1530.341	(-)-8.91	29.52	(InB nf)-38.43	0.060	0.159	0.000
3	1531.113	(-)-9.07	23.06	(InB nf)-32.12	0.057	0.170	0.000
4	1531.925	(-)-10.29	19.68	(InB nf)-29.97	0.058	0.268	0.000
5	1532.704	(-)-8.13	32.65	(InB nf)-40.78	0.059	0.160	0.000
6	1534.260	(-)-9.78	22.14	(InB nf)-31.91	0.055	0.168	0.000
7	1535.033	(-)-9.89	17.97	(InB nf)-27.86	0.065	0.406	0.000
8	1535.832	(-)-6.04	34.35	(InB nf)-40.38	0.067	0.220	0.000
9	1537.432	(-)-11.91	26.46	(InB nf)-38.36	0.062	0.201	0.000
10	1538.209	(-)-9.80	16.06	(InB nf)-25.87	0.061	0.483	0.000
11	1538.967	(-)-6.10	24.13	(InB nf)-30.23	0.058	0.169	0.000
12	1540.574	(-)-6.57	21.05	(InB nf)-27.62	0.062	0.198	0.000
13	1542.172	(-)-9.20	21.05	(InB nf)-30.25	0.056	0.191	0.000
14	1542.932	(-)-10.34	20.34	(InB nf)-30.68	0.060	0.243	0.000
15	1544.576	(-)-10.00	19.24	(InB nf)-29.24	0.062	0.381	0.000
16	1546.158	(-)-8.20	30.84	(InB nf)-39.04	0.063	0.214	0.000
17	1546.924	(-)-6.92	33.81	(InB nf)-40.74	0.059	0.163	0.000
18	1547.730	(-)-9.09	30.28	(InB nf)-39.37	0.061	0.217	0.000
19	1548.532	(-)-10.70	20.94	(InB nf)-31.64	0.062	0.277	0.000
20	1549.333	(-)-6.79	34.12	(InB nf)-40.91	0.067	0.217	0.000
21	1550.132	(-)-10.73	20.33	(InB nf)-31.06	0.065	0.353	0.000
22	1550.948	(-)-10.56	21.17	(InB nf)-31.73	0.062	0.280	0.000
23	1551.742	(-)-6.67	34.30	(InB nf)-40.97	0.063	0.208	0.000
24	1552.536	(-)-6.21	34.40	(InB nf)-40.60	0.064	0.215	0.000
25	1553.309	(-)-8.91	24.03	(InB nf)-32.94	0.058	0.171	0.000
26	1554.169	(-)-11.45	27.90	(InB nf)-39.35	0.058	0.163	0.000

Managing Results


Viewing WDM Graph in Full-Screen Mode


Viewing WDM Graph in Full-Screen Mode

The full-screen mode allows you to see the WDM graph, including the markers, using the whole screen of your unit. It also displays three lines of results.

If you have only an active trace, the results show three channels. If you have an active trace and a reference channel, you will see the results for one channel.

To display the trace in full-screen mode:

Use the  button located on the upper right-hand section of the graph.



To change channels

To view other channel results

Using Zoom Controls

Use the zoom controls to change the scale of the trace display.


You can zoom in on or out of the graph using the corresponding buttons or let the application automatically adjust the zoom on the currently selected peak from the results table.

You can quickly zoom in on or out of a selected peak.

You can also return to the original graph value.

The application provides an automatic zoom on peak feature. When this feature is activated and you press on a row in the peak results grid, the graph will zoom and tab show that peak covering 33 % of the graph canvas. By default, this option is deactivated.

Note: *You cannot select channels on the graph when the markers are displayed.*







Note: *You can only move the markers with the  button.*


Managing Results

Using Zoom Controls

To view specific portions of the graph:

- You can define which portion of the graph will be visible by pressing  and dragging the graph with the stylus or your finger.
- You can also zoom in on a specific area by pressing  and defining the zoom area with the stylus or your finger (a rectangle with dotted lines will appear to help you define the area). Once you release the stylus, the application automatically zooms in on the graph.
- You can zoom in or out on the center of the portion of the graph that is displayed by using, respectively,  or . The application automatically adjusts the zoom by 50 % and 100 % respectively.

To automatically zoom in on the selected peak:

Select the peak on the graph or in the table results and press .

To revert to the complete graph view:

Press .

Managing Markers

You can use markers to perform manual measurements and verification directly on the trace. All test modes feature two vertical markers and two horizontal markers. The vertical markers are used to indicate the power level on the trace at the wavelength or frequency it is positioned, and the horizontal markers are used for indicating power at the level they are. You can measure actual power and wavelength values of any point on the trace using the vertical markers.

Note: *Horizontal markers will be displayed only if the markers are activated in the **Preferences** tab of the related test mode.*

Each marker is identified by a letter: A and B are for vertical markers, and C and D for horizontal markers.

The application allows you to fix the distance between the markers. When this feature is activated, while moving any one marker, both markers will move at the same rate and distance.

Markers A and B in the marker toolbar act as toggle buttons to enable selection. When a marker is activated, the color of the button changes to orange and the selected marker displays a double arrow at the base of the marker in the graph tab, which means that the marker can be moved.

At this point, if you select the other vertical marker in the graph tab, the selection of the toggle switches to this marker. However, if you select the other marker button from the marker toolbar, both markers will be selected and the distance between both will be locked.

Note: *If you select a vertical marker while the horizontal markers are active, the selection will toggle to the other type of marker and vice versa.*

Note: *If you zoom into the graph, or pan within it, the markers remain in their set positions.*

Managing Results

Managing Markers

You can also use the automated marker positioning to place the markers around a specific channel peak. The positions are set from the results grid, according to the following by default:

- A: set at the peak wavelength “ λ Peak(nm)” or frequency “f peak(Thz)”.
- B: set at the wavelength/frequency which corresponds to a 3 dB drop from the peak maximum power (Signal power “p” without subtracting the noise).
- C: set at the peak power (λ Peak).
- D: set at 3 dB below marker C.


If you move one of the markers, these new settings are kept for the next use of the automated markers until you reset them or select another zoom feature.

If the channel you select does not display a signal, the markers remain in the position that they were before.


In the case of the WDM and Drift modes, the markers are placed on the active trace. In the case of EDFA testing, the markers will be on the output trace.

To display the marker toolbar:


Press the  button on the top left-hand corner of the display.




To display the automated markers:

Press the  button. The focus will be done on the currently selected channel in the **Results** tab.

To manually enter a marker position value:

1. If you have not done so already, press the  button on the top left-hand corner of the display to make the marker toolbar appear.



2. Set the marker by entering precise values in the box corresponding to it or by dragging it on-screen.

As markers A and B appear on the graph, the following values will be displayed in the marker toolbar.

- power values corresponding to the wavelength position of both markers (in the case of WDM, the active and reference values are displayed; in the case of spectral transmittance and EDFA, the input and output values are displayed).
- wavelength or frequency difference between the markers (A-B)
- power difference in dB between the markers

Managing Results

Managing Markers

- integrated power between the markers in dBm (when horizontal markers are hidden)
- for WDM, spectral transmittance and EDFA modes, power difference between the traces (active against reference or input against output) for both markers in dB (when horizontal markers are hidden).

As markers C and D appear on the graph, the power difference between the markers (C-D) related to the horizontal markers will be displayed in the marker toolbar.

You can also move the markers directly on the graph tab. Drag the marker to the desired area in the display. You will notice that the corresponding box in the marker toolbar changes according to the marker's position. If you want to set a precise value for the marker, simply enter it in the box.

Note: *After using the zoom tools in the graph tab, you can only move the markers again on the graph after deactivating the zoom. Pressing the arrow in the zoom tools section will deactivate the zoom function.*

Note: *Markers A and B cannot cross. Displacing a marker over the second one will cause both markers to move together.*

Managing Trace Information


After acquiring a trace, you might want to view details about the acquisition. The **Trace Info.** tab shows information related to acquisition parameters and conditions. You can also edit information about the tested fiber and job or add comments. This information is saved along with the trace.

Note: *Trace information is available for both active and reference traces, but you can edit only the trace information pertaining to the active trace.*


Note: *If you want to apply the settings of the **Trace Identification** window to the **Preferences** tab, select the **Use as template** option and press **OK**.*

To view trace information parameters:

1. From the main window, select the **Trace Info.** tab.



2. For some test types (WDM if there is a reference trace, spectral transmittance and EDFA), select which trace you want to view.




Managing Results

Managing Trace Information


To edit general information:

1. From the main window, select the **Trace Info.** tab.
2. Press **Trace Identification.**



Note: Trace identification is not available for the WDM reference trace.

3. Select the **General** tab.




4. Edit the general information as required.
5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Clear** to clear all the changes made in the **General** tab.

To edit trace information:

1. From the main window, select the **Trace Info.** tab.
2. Press **Trace Identification.**



3. Select the **Information** tab.



4. Edit the information as required.
5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.


Press **Restore Defaults** to remove all the changes and apply the default values.

Managing Results


Managing Trace Information

To edit comments:

1. From the main window, select the **Trace Info.** tab.
2. Press **Trace Identification.**



3. Select the **Comments** tab.



4. Edit comments in the **Comments** window for the current trace.
5. Press **OK** to save the changes and close the window, or press **Cancel** to exit without saving.

Press **Clear** to clear all the changes made in the **Comments** tab.

Generating Reports


After performing any acquisition, you can generate a report for the current acquisition and save it in .html, PDF or .txt format depending on the supported file type for your test mode. The report file will include trace information, acquisition conditions and other results and details specific to each test mode.

Note: Empty channels that are shown on screen are included in the report files.

Note: The .txt format report type is only available for the WDM and Drift modes.

To generate a report:

1. From the **Main Menu**, select **File**.
2. Press **Report**.




3. In the **Save As** window, enter a file name.

Managing Results

Generating Reports

4. From the **Save as type** list, select the format for your report.



5. Press **Save**. The report will be added to the **Reports** folder. You can change the location where you want to save the report as desired.

14 Maintenance

To help ensure long, trouble-free operation:

- Always inspect fiber-optic connectors before using them and clean them if necessary.
- Keep the unit free of dust.
- Clean the unit casing and front panel with a cloth slightly dampened with water.
- Store unit at room temperature in a clean and dry area. Keep the unit out of direct sunlight.
- Avoid high humidity or significant temperature fluctuations.
- Avoid unnecessary shocks and vibrations.
- If any liquids are spilled on or into the unit, turn off the power immediately, disconnect from any external power source, remove the batteries and let the unit dry completely.



WARNING

The use of controls, adjustments and procedures other than those specified herein may result in exposure to hazardous situations or impair the protection provided by this unit.

Cleaning EUI Connectors

Regular cleaning of EUI connectors will help maintain optimum performance. There is no need to disassemble the unit.



IMPORTANT

If any damage occurs to internal connectors, the module casing will have to be opened and a new calibration will be required.

Maintenance

Cleaning EUI Connectors




WARNING


Looking into the optical connector while the light source is active **WILL** result in permanent eye damage. EXFO strongly recommends to **TURN OFF** the unit before proceeding with the cleaning procedure.

To clean EUI connectors:

1. Remove the EUI from the instrument to expose the connector baseplate and ferrule.



2. Moisten a 2.5 mm cleaning tip with *one drop* of isopropyl alcohol (alcohol may leave traces if used abundantly).
3. Slowly insert the cleaning tip into the EUI adapter until it comes out on the other side (a slow clockwise rotating movement may help).



4. Gently turn the cleaning tip one full turn, then continue to turn as you withdraw it.
5. Repeat steps 3 to 4 with a dry cleaning tip.

Note: Make sure you don't touch the soft end of the cleaning tip.

6. Clean the ferrule in the connector port as follows:

6a. Deposit *one drop* of isopropyl alcohol on a lint-free wiping cloth.



IMPORTANT

Isopropyl alcohol may leave residues if used abundantly or left to evaporate (about 10 seconds).

Avoid contact between the tip of the bottle and the wiping cloth, and dry the surface quickly.

6b. Gently wipe the connector and ferrule.

6c. With a dry lint-free wiping cloth, gently wipe the same surfaces to ensure that the connector and ferrule are perfectly dry.

6d. Verify connector surface with a portable fiber-optic microscope (for example, EXFO's FOMS) or fiber inspection probe (for example, EXFO's FIP).

7. Put the EUI back onto the instrument (push and turn clockwise).

8. Throw out cleaning tips and wiping cloths after one use.

Recalibrating the Unit

EXFO manufacturing and service center calibrations are based on the ISO/IEC 17025 standard (*General Requirements for the Competence of Testing and Calibration Laboratories*). This standard states that calibration documents must not contain a calibration interval and that the user is responsible for determining the re-calibration date according to the actual use of the instrument.

The validity of specifications depends on operating conditions. For example, the calibration validity period can be longer or shorter depending on the intensity of use, environmental conditions and unit maintenance, as well as the specific requirements for your application. All of these elements must be taken into consideration when determining the appropriate calibration interval of this particular EXFO unit.

Under normal use, the recommended interval for your FTB-5240S/S-P Optical Spectrum Analyzer is: one year.

For newly delivered units, EXFO has determined that the storage of this product for up to six months between calibration and shipment does not affect its performance (EXFO Policy PL-03).

To help you with calibration follow-up, EXFO provides a special calibration label that complies with the ISO/IEC 17025 standard and indicates the unit calibration date and provides space to indicate the due date. Unless you have already established a specific calibration interval based on your own empirical data and requirements, EXFO would recommend that the next calibration date be established according to the following equation:

Next calibration date = Date of first usage (if less than six months after the calibration date) + Recommended calibration period (one year)

To ensure that your unit conforms to the published specifications, calibration may be carried out at an EXFO service center or, depending on the product, at one of EXFO's certified service centers. Calibrations at EXFO are performed using standards traceable to national metrology institutes.

Note: *You may have purchased a FlexCare plan that covers calibrations. See the Service and Repairs section of this user documentation for more information on how to contact the service centers and to see if your plan qualifies.*

Recycling and Disposal (Applies to European Union Only)

For complete recycling/disposal information as per European Directive WEEE 2012/19/UE, visit the EXFO Web site at www.exfo.com/recycle.

15 Troubleshooting


Viewing Online Documentation

An online version of the FTB-5240S/S-P Optical Spectrum Analyzer user guide is available at all times from the application.

Note: You will also find a printable PDF version on your installation DVD.

To access online help:

At the bottom of the **Main Menu**, tap .



Troubleshooting

Contacting the Technical Support Group

Contacting the Technical Support Group

To obtain after-sales service or technical support for this product, contact EXFO at one of the following numbers. The Technical Support Group is available to take your calls from Monday to Friday, 8:00 a.m. to 7:00 p.m. (Eastern Time in North America).

Technical Support Group

400 Godin Avenue
Quebec (Quebec) G1M 2K2
CANADA

1 866 683-0155 (USA and Canada)
Tel.: 1 418 683-5498
Fax: 1 418 683-9224
support@exfo.com

For detailed information about technical support, and for a list of other worldwide locations, visit the EXFO Web site at www.exfo.com.


If you have comments or suggestions about this user documentation, you can send them to customer.feedback.manual@exfo.com.

To accelerate the process, please have information such as the name and the serial number (see the product identification label), as well as a description of your problem, close at hand.

You may also be requested to provide software and module version numbers. This information, as well as technical support contact information, can be found in the **About** window.

To view the information about the product:

From the Main Menu, press .



Transportation

Maintain a temperature range within specifications when transporting the unit. Transportation damage can occur from improper handling. The following steps are recommended to minimize the possibility of damage:

- Pack the unit in its original packing material when shipping.
- Avoid high humidity or large temperature fluctuations.
- Keep the unit out of direct sunlight.
- Avoid unnecessary shocks and vibrations.



IMPORTANT

Keep this information close at hand, as it contains important details about your product.



CAUTION

- Always use the GP-10-055 case when transporting the FTB-5240S module. EXFO does not recommend transporting the modules in a platform and/or in a case other than the one designed for your specific module.
- Handle the case with care when transporting the module.
- Please follow these guidelines. Modules damaged from rough handling during transport or shipment are not covered by any EXFO warranty.

The following image show the GP-10-055 case with the module inside.



16 Warranty

General Information

EXFO Inc. (EXFO) warrants this equipment against defects in material and workmanship for a period of one year from the date of original shipment. EXFO also warrants that this equipment will meet applicable specifications under normal use.

During the warranty period, EXFO will, at its discretion, repair, replace, or issue credit for any defective product, as well as verify and adjust the product free of charge should the equipment need to be repaired or if the original calibration is erroneous. If the equipment is sent back for verification of calibration during the warranty period and found to meet all published specifications, EXFO will charge standard calibration fees.



IMPORTANT

The warranty can become null and void if:

- unit has been tampered with, repaired, or worked upon by unauthorized individuals or non-EXFO personnel.
- warranty sticker has been removed.
- case screws, other than those specified in this guide, have been removed.
- case has been opened, other than as explained in this guide.
- unit serial number has been altered, erased, or removed.
- unit has been misused, neglected, or damaged by accident.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL EXFO BE LIABLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

Warranty

Liability

Liability

EXFO shall not be liable for damages resulting from the use of the product, nor shall be responsible for any failure in the performance of other items to which the product is connected or the operation of any system of which the product may be a part.

EXFO shall not be liable for damages resulting from improper usage or unauthorized modification of the product, its accompanying accessories and software.

Exclusions

EXFO reserves the right to make changes in the design or construction of any of its products at any time without incurring obligation to make any changes whatsoever on units purchased. Accessories, including but not limited to fuses, pilot lamps, batteries and universal interfaces (EUI) used with EXFO products are not covered by this warranty.

This warranty excludes failure resulting from: improper use or installation, normal wear and tear, accident, abuse, neglect, fire, water, lightning or other acts of nature, causes external to the product or other factors beyond the control of EXFO.



IMPORTANT

In the case of products equipped with optical connectors, EXFO will charge a fee for replacing connectors that were damaged due to misuse or bad cleaning.

Certification

EXFO certifies that this equipment met its published specifications at the time of shipment from the factory.

Service and Repairs

EXFO commits to providing product service and repair for five years following the date of purchase.

To send any equipment for service or repair:

1. Call one of EXFO's authorized service centers (see *EXFO Service Centers Worldwide* on page 337). Support personnel will determine if the equipment requires service, repair, or calibration.
2. If equipment must be returned to EXFO or an authorized service center, support personnel will issue a Return Merchandise Authorization (RMA) number and provide an address for return.
3. If possible, back up your data before sending the unit for repair.
4. Pack the equipment in its original shipping material. Be sure to include a statement or report fully detailing the defect and the conditions under which it was observed.
5. Return the equipment, prepaid, to the address given to you by support personnel. Be sure to write the RMA number on the shipping slip. *EXFO will refuse and return any package that does not bear an RMA number.*

Note: *A test setup fee will apply to any returned unit that, after test, is found to meet the applicable specifications.*

After repair, the equipment will be returned with a repair report. If the equipment is not under warranty, you will be invoiced for the cost appearing on this report. EXFO will pay return-to-customer shipping costs for equipment under warranty. Shipping insurance is at your expense.

Routine recalibration is not included in any of the warranty plans. Since calibrations/verifications are not covered by the basic or extended warranties, you may elect to purchase FlexCare Calibration/Verification Packages for a definite period of time. Contact an authorized service center (see *EXFO Service Centers Worldwide* on page 337).

EXFO Service Centers Worldwide

If your product requires servicing, contact your nearest authorized service center.

EXFO Headquarters Service Center

400 Godin Avenue
Quebec (Quebec) G1M 2K2
CANADA

1 866 683-0155 (USA and Canada)
Tel.: 1 418 683-5498
Fax: 1 418 683-9224
support@exfo.com

EXFO Europe Service Center

Winchester House, School Lane
Chandlers Ford, Hampshire S053 4DG
ENGLAND

Tel.: +44 2380 246800
Fax: +44 2380 246801
support.europe@exfo.com

EXFO Telecom Equipment (Shenzhen) Ltd.

3rd Floor, Building 10,
Yu Sheng Industrial Park (Gu Shu
Crossing), No. 467,
National Highway 107,
Xixiang, Bao An District,
Shenzhen, China, 518126

Tel: +86 (755) 2955 3100
Fax: +86 (755) 2955 3101
support.asia@exfo.com

A Technical Specifications



IMPORTANT

The following technical specifications can change without notice. The information presented in this section is provided as a reference only. To obtain this product's most recent technical specifications, visit the EXFO Web site at www.exfo.com.

SPECTRAL MEASUREMENT		
	FTB-5240S and FTB-5240S-P	FTB-5240BP
Wavelength range (nm)	1250 to 1650	1250 to 1650
Wavelength uncertainty (nm) ^b	±0.05 ±0.01 ^{c,d}	±0.03 ±0.01 ^{c,d}
Reference	Internal ^a	Internal
Resolution bandwidth (FWHM) (nm) ^f	0.065 ^{b,d}	0.033 ^{b,d}
Wavelength linearity (nm)	±0.01 ^{b,d}	±0.01 ^{b,d}
Wavelength repeatability 2 σ (nm)	±0.003 ^g	±0.002 ^g

POWER MEASUREMENT			
	FTB-5240S and FTB-5240S-P	FTB-5240BP	HPW Option
Dynamic range (dBm) (per channel) ^b	-80 ^h to +18	-80 ^h to +18	-70 ^h to +23
Maximum total safe power (dBm)	+23	+23	+29
Absolute power uncertainty (dB) ⁱ	±0.5	±0.5	±0.5
Power repeatability 2 σ (dB) ^{4,9}	±0.05	±0.04	±0.05

OPTICAL MEASUREMENT			
	FTB-5240S and FTB-5240S-P	FTB-5240BP	HPW Option
Optical rejection ratio at 1550 nm (dB) at 0.2 nm (25 GHz) at 0.4 nm (50 GHz)	35 (40 typical) 45 (50 typical)	45 (50 typical) 50 (55 typical)	35 (40 typical) 45 (50 typical)
Channel spacing	25 to 200 GHz CWDM	12.5 to 200 GHz CWDM	25 to 200 GHz CWDM
PDL at 1550 nm (dB)	±0.08 ^d	±0.06 ^d	
ORL (dB)	≥40	≥40	
Measurement time (s) ^{4,i} (includes scanning, analysis and display)	<1 (with the FTB-500 Platform)	<1 (with the FTB-500 Platform)	

Technical Specifications

IN-BAND OSNR MEASUREMENT ^{d, k}		
	FTB-5240S-P only	FTB-5240BP
OSNR dynamic range (dB)	>35 ^l	>35 ^l
OSNR measurement uncertainty (dB)	±0.5 ^m	±0.5 ^m
Repeatability (dB)	±0.2 ⁿ	±0.2 ⁿ
Data signals	Up to 100 Gbit/s ^o	Up to 100 Gbit/s ^o
Measurement time (s) ^{d, i} (includes scanning, analysis and display)	<6 (eight scans)	<6 (eight scans)
Analysis modes	WDM, EDFA, drift, spectral transmittance, DFB, BP	WDM, EDFA, drift, spectral transmittance, DFB

Notes

- All specifications are for a temperature of 23 °C ± 2 °C with an FC/UPC connector unless otherwise specified, after warm-up.
- From 1520 to 1610 nm.
- After user calibration in the same test session within 10 nm from each calibration point.
- Typical.
- Integrated and wavelength-independent self-adjustment.
- Full width at half maximum.
- Over one minute in continuous acquisition mode.
- With averaging.
- At 1550 nm, -10 dBm input.
- 45 nm span, full resolution, 20 peak analysis.
- In-band OSNR measurement performed with 64 scans.
- For an optical noise level of > -60 dBm.
- With PMD ≤15 ps and no crosstalk, uncertainty specification is valid for OSNR ≤ 25 dB. With PMD ≤15 ps and crosstalk, uncertainty specification is valid for OSNR ≤ 20 dB.
- Repeatability specification is valid for OSNR ≤ 25 dB.
- Except for pol-mux and fast polarization scrambled signals.

GENERAL SPECIFICATIONS		
Temperature	operating storage	0 °C to 40 °C (32 °F to 104 °F) -20 °C to 50 °C (-4 °F to 120 °F)
Relative humidity		0 % to 95 % noncondensing
Battery life (hours)		5 (with the FTB-500 Platform)
Connectors		EI (EXFO UPC Universal Interface) EA (EXFO APC Universal Interface)
Size (H x W x D)	FTB-5240S module FTB-5240BP module	96 mm x 51 mm x 260 mm (3 ¾ in x 2 in x 10 ¼ in) 96 mm x 76 mm x 260 mm (3 ¾ in x 3 in x 10 ¼ in)
Weight	FTB-5240S module FTB-5240BP module	1.5 kg (3.3 lb) 1.7 kg (3.8 lb)

SELECTION GUIDE				
OSA Module	CWDM	DWDM (100 GHz spacing)	DWDM (50 GHz spacing)	ROADM + 40 Gbit/s network
FTB-5240S	X	X	X	
FTB-5240S-P	X	X	X	X
FTB-5240BP	X	X	X	X

B *Formulas Used with Your Optical Spectrum Analyzer*

The following formulas are used in the various tests available with your OSA module.

EDFA Noise Figure Calculation

The EDFA noise figure is calculated using the following equation:

$$\text{EDFA noise figure} = \frac{P_{\text{ASE}} - GP_{\text{SSE}}}{Gh\nu B} + \frac{1}{G}$$

Where

P_{ASE} is the power of the spontaneous emission amplified by the EDFA,

P_{SSE} is the power of the spontaneous emission of the source,

G is the gain at this channel's wavelength,

h is Plank's constant ($6,6256 \times 10^{-34} \text{ J} \cdot \text{s}$),

ν is the frequency of the channel, and

B is the noise equivalent bandwidth, as calibrated at this channel's wavelength.

Formulas Used with Your Optical Spectrum Analyzer

Central Wavelength Calculation (Spectral Transmittance)

Central Wavelength Calculation (Spectral Transmittance)

The central wavelength is calculated using the following equation:

$$a = \frac{\lambda_R + \lambda_L}{2}$$

Where

a is the central wavelength,

λ_R is the wavelength on the right at which the power is 3 dB below the power at the nominal wavelength, and

λ_L is the wavelength on the left at which the power is 3 dB below the power at the nominal wavelength.

Bandwidth Calculation (Spectral Transmittance)

Bandwidth is calculated using the following equation:

$$b = 2 * \text{Min}\{(\lambda_N - \lambda_{XdBLeft}), (\lambda_{XdBRight} - \lambda_N)\}$$

Where

b is the bandwidth at X dB,

λ_N is the nominal wavelength,

$\lambda_{XdBLeft}$ is the wavelength on the left at which the power is X dB below the power at the nominal wavelength.

$\lambda_{XdBRight}$ is the wavelength on the right at which the power is X dB below the power at the nominal wavelength.

Index

A

- acquisition
 - averaging..... 86, 131, 160, 173, 195, 232
 - i-inband..... 86
 - inband..... 86
 - real-time..... 86, 160, 173, 195, 232
 - single..... 86, 131, 160, 173, 195, 232
 - type..... 39, 161
- activating
 - default channel..... 64, 111, 220
 - thresholds..... 73, 122
- adjacent channel isolation..... 297
- after-sales service..... 328
- analysis parameters
 - drift..... 107
 - WDM..... 59
- analysis setup
 - discover feature..... 239
 - importing..... 255
- application, starting..... 15
- average
 - gain..... 305
 - OSNR..... 73
 - signal power..... 73
 - signal power, input..... 304
 - signal power, output..... 304
- averaging
 - acquisition..... 131
 - acquisition type..... 86, 173, 195, 232

B

- bandwidth
 - at 3 dB..... 58, 289
 - at x dB..... 58, 69, 116
 - calculation..... 343
 - resolution..... 115, 222
 - resolution for OSNR..... 68

C

- cable ID..... 39
- calculation
 - bandwidth..... 343
 - central wavelength..... 342
 - EDFA noise figure..... 341
- carrier leakage..... 273
- caution
 - of personal hazard..... 6
 - of product hazard..... 6
- center
 - frequency..... 58, 77, 106, 214, 289, 293
 - wavelength..... 58, 77, 106, 214, 289, 293
- central
 - offset..... 290
 - wavelength calculation..... 342
- certification information.....vi
- channel
 - adjacent isolation..... 297
 - center, wavelength or frequency .. 80, 125, 226
 - count, empty..... 73
 - definition..... 192
 - gain..... 214
 - increment value..... 126
 - increment value, name..... 81
 - name..... 58, 214
 - noise..... 58
 - reference value..... 282
 - results..... 268
 - spacing..... 80, 126, 226
 - spectral peak..... 59
 - total power..... 66, 113
 - width..... 65, 80, 112, 126, 221, 226
- channel characteristics
 - carved noise..... 272
 - Pol-Mux..... 272

Index

- cleaning
 - EUI connectors..... 321
 - fiber ends 17
 - front panel 321
- clearing
 - default channel..... 220
 - trace 245
- comments, entering 48, 168, 182
- connectors, cleaning 321
- conventions, safety 6
- current
 - drift value 282
 - output power 214
- customer service..... 336
- customized drift measurement 138
- customizing
 - drift results 105
 - EDFA results..... 213
 - WDM results..... 57

D

- dashboard, WDM Investigator 271
- default
 - channel, activating 64, 111, 220
 - thresholds..... 74
- definition, channel 192
- deleting
 - test configuration 258
 - trace 245
- description of location 47, 96, 181, 204
- detected modes power 293
- detecting module..... 12
- detection level, peak 68, 115, 222
- deviation
 - spectral center of mass..... 59
 - spectral peak 59
 - wavelength..... 122, 269
- DFB mode 149
- discover feature..... 239
- display parameter 50

- distance
 - channel 80
 - OSNR 67, 114
- drift
 - current value..... 282
 - customized measurement..... 138
 - maximum value 282
 - minimum value 282
 - mode 91
 - parameters..... 107
 - preferences 93
 - time for minimum value 282

E

- EDFA
 - analysis parameters..... 215
 - mode 199
 - noise figure..... 215
 - noise figure calculation 341
 - preferences 201
- electrical offsets, nulling..... 23
- element, network 47
- empty channel count..... 73
- end range 125, 226
- entering comments 48, 168
- equipment returns..... 336
- error factor, gaussian fit..... 293
- EUI
 - baseplate 19
 - connector adapter 19
 - dust cap..... 19
- EUI connectors, cleaning 321
- EXFO universal interface. see EUI

F

- Fabry-Perot
 - mode 163
 - mode spacing 290
 - preferences 164
- fail threshold limits..... 119
- fiber ends, cleaning 17

fiber ID 39
 fifth order polynomial fit..... 67, 114
 files
 managing 242
 opening 243
 saving 242
 fit
 fifth order polynomial..... 67, 114
 width 294
 zone 67, 114
 flatness
 gain 304
 input signal power..... 304
 OSNR 73
 output signal power 304
 signal power 73
 frequency
 center 58, 106, 214, 289, 293
 central 77
 channel center 80, 125, 226
 peak mode..... 294
 range 39
 front panel, cleaning 321
 FWHM 293

G

gain
 average 305
 channel..... 214
 flatness 304
 slope 305
 gaussian fit error factor..... 293
 general preferences 62, 93, 164
 generating report..... 319
 global results..... 70, 270, 304
 graph tab 262

H

help. see online user guide

I

ID prefix link 96
 identification label..... 328
 i-inband method..... 86
 impairments
 carrier leakage 273
 interchannel crosstalk 273
 non linear depolarization 273
 PMD pulse spreading 273
 importing analysis setup..... 255
 inband method..... 86, 131
 increment
 channel value..... 81, 126, 227
 starting value, link ID 167
 information
 link and location 45, 180
 system under test..... 96, 181, 204
 input
 power offset 222
 signal power 214
 signal power average 304
 signal power flatness 304
 value position 313
 wavelength, offset 222
 inserting a module 9
 integrated power..... 65, 112
 interchannel crosstalk..... 273
 ITU grid 65, 112, 221

L

label, identification..... 328
 left
 SMSR 289
 stopband 290
 level
 detection, peak 222
 noise 77
 levels of information..... 273
 link
 ID 39, 153
 information..... 45, 166, 180

Index

orientation..... 46, 96, 181, 204
prefix 46, 96, 153, 167, 181, 204
starting value.... 46, 81, 96, 126, 153, 167,
181, 204, 227

location
description..... 39, 47, 96, 181, 204
information 45, 166, 180

M

maintenance
EUI connectors..... 321
front panel 321
general information..... 321

managing
results..... 261
traces..... 242

markers 311

maximum
drift value 282
time for drift..... 282

measurement
customized, drift 138
starting..... 237

minimum
time value, drift 282
value during drift..... 282
warm up period..... 17

mode
DFB 149
drift 91
EDFA..... 199
Fabry-Perot 163
power, peak..... 293
spacing..... 294
spectral transmittance 177
test 4
WDM 41

module
detection 12
insertion 9
removal 9

mounting EUI connector adapter 19
MTSM at 10 dB..... 294

N

name
channel 58, 214
prefix 80, 126, 227
network element 47, 96, 181, 204

noise
carved 272
channel 58, 77
curve calculation 67, 114
figure, EDFA..... 215
OSNR 66, 113
region 67, 114

non linear depolarization 273

nulling electrical offsets 23

O

offline application 5

offset
central..... 290
input power 222
input wavelength..... 222
nulling 23
output power 223
output wavelength 223
power 69, 116
wavelength 69, 116

online user guide..... 327

opening files
other formats in WDM mode 246
trace 243
WDM trace in DFB mode..... 247
WDM trace in EDFA mode 249
WDM trace in FP mode 247
WDM trace in ST mode 248

options 4

orientation, link 46, 96, 181, 204

- OSA
- description 1
 - offline 5
 - typical applications 3
- OSNR 58, 77, 106, 122
- average 73
 - distance 67, 114
 - flatness 73
 - noise 66, 113
 - resolution bandwidth 68
- output
- power offset 223
 - signal power 214
 - signal power average 304
 - signal power flatness 304
 - value position 313
 - wavelength offset 223
- P**
- parameters
- display 50
 - drift 107
 - general 62
- PASE 214
- pass threshold limits 119
- PDF. see online user guide
- peak
- detection level 68, 115, 222
 - indicator 264, 282, 302
 - mode frequency 294
 - mode power 293
 - mode wavelength 294
 - power signal 289
 - signal power 66, 113
- PMD pulse spreading 273
- polyfit method 67, 114
- position, worst case SMSR 290
- post-processing application 5
- power
- detected modes 293
 - difference 313
 - integrated 65, 112, 314
 - offset 69, 116
 - output, current 214
 - peak 66, 113
 - signal 58, 65, 77, 106, 112, 122
 - total 293
 - total channel 66, 113
 - value of wavelength position 313
- preferences
- comments 48, 154, 168, 182, 205
 - DFB 150
 - drift 93
 - EDFA 201
 - Fabry-Perot 164
 - general 43, 93, 150, 164
 - information 45, 152, 180
 - ST 178
 - WDM 43
- prefix
- link ID 96, 167, 181, 204
 - name 80, 126, 227
- preparing OSA for a test 17
- product
- identification label 328
 - specifications 339
- PSSE 214
- R**
- range
- frequency 39
 - start 80, 125, 226
 - stop 80, 125, 226
 - wavelength 39
- real-time acquisition mode .. 86, 173, 195, 232
- reference, channel 282
- region, noise 67, 114
- removing a module 9
- report, generating 319
- resolution bandwidth 115, 222
- resolution bandwidth, OSNR 68
- results 57

Index

channels	268
customizing	105
global	70, 304
tab	270
viewing	261
WDM investigator.....	271
return merchandise authorization (RMA) ..	336
right	
SMSR	289
stopband	290
RMS width	293

S

S %.....	214
safety	
caution	6
conventions	6
warning	6
saving traces	242
scan count.....	39
service and repairs.....	336
service centers.....	337
setting up WDM mode.....	41
settings, general.....	62
setup	
analysis	239
importing	255
shipping to EXFO	336
signal power	66
average.....	73
calculation	65, 112
channel.....	58, 77, 106, 122
flatness	73, 304
input.....	214
output	214
peak.....	113, 289
signal to noise ratio.....	67, 114
single acquisition mode.....	86, 131, 173, 195, 232
slope, gain	305

SMSR	
left	289
right.....	289
worst case.....	290
worst case position	290
snap to ITU grid.....	65, 112, 221
softband, right	290
software packages.....	4
software. see application	
spacing	
channels.....	226
Fabry-Perot mode	290
mode	294
spacing, channels.....	126
specifications, product	339
spectral center of mass, deviation	59
spectral peak	59
spectral peak, deviation.....	59
spectral transmittance	
calculation	342, 343
mode	177
swapping traces.....	299
spontaneous emission power	214
start range.....	80, 125, 226
starting measurement	237
starting value, link	81, 96, 126, 204, 227
statuses	275
stop range.....	125, 226
stopband, left.....	290
storage requirements	321
suffix increment, link ID.....	204
swapping ST traces.....	299
switching test modes	22
symbols and meaning	273, 275
symbols, safety.....	6
system information	46, 96, 181, 204

T

T max.....	282
T min for drift.....	282
tab, graph	262

- technical specifications..... 339
 - technical support 328
 - temperature for storage..... 321
 - test
 - configuration, deleting 258
 - modes..... 4
 - point..... 47, 96, 204
 - results, WDM..... 262
 - switching modes 22
 - threshold limits 119
 - thresholds
 - activating..... 73, 122
 - default 74
 - time of drift for maximum value 282
 - total channel power 66, 113
 - total power 293
 - trace
 - clearing..... 245
 - managing 242
 - opening 243
 - saving 242
 - transportation requirements 321, 330
 - typical applications 3
- U**
- user guide. see online user guide
- V**
- value
 - channel name, increment 81
 - increment 227
 - link start 126
- W**
- warm up period 17
 - warranty
 - certification 335
 - exclusions 335
 - general 333
- liability..... 334
 - null and void..... 333
 - wavelength
 - center..... 58, 106, 214, 289, 293
 - central..... 77
 - channel center 80, 125, 226
 - deviation..... 122, 269
 - difference..... 313
 - offset 69, 116
 - peak mode..... 294
 - range 39
 - WDM
 - analysis parameters..... 59
 - general settings 62
 - opening files in other formats..... 246
 - results, customizing 105
 - setting up mode 41
 - test results 262
 - WDM Investigator results 271
 - WDM trace
 - DFB mode 247
 - EDFA mode 249
 - FP mode..... 247
 - ST mode..... 248
 - width
 - channels..... 65, 80, 112, 126, 221, 226
 - RMS 293
 - worst case SMSR 290
- Z**
- zoom controls 309

NOTICE

通告

CHINESE REGULATION ON RESTRICTION OF HAZARDOUS SUBSTANCES 中国关于危害物质限制的规定

NAMES AND CONTENTS OF THE TOXIC OR HAZARDOUS SUBSTANCES OR ELEMENTS CONTAINED IN THIS EXFO PRODUCT



包含在本 **EXFO** 产品中的有毒有害物质或元素的名称和含量

O	Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363-2006 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。
X	Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363-2006 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。

Part Name 部件名称	Toxic or hazardous Substances and Elements 有毒有害物质和元素					
	Lead 铅 (Pb)	Mercury 汞 (Hg)	Cadmium 镉 (Cd)	Hexavalent Chromium 六价铬 (Cr VI)	Polybrominated biphenyls 多溴联苯 (PBB)	Polybrominated diphenyl ethers 多溴二苯醚 (PBDE)
Enclosure 外壳	O	O	O	O	O	O
Electronic and electrical sub-assembly 电子和电子组件	X	O	X	O	X	X
Optical sub-assembly ^a 光学组件 ^a	X	O	O	O	O	O
Mechanical sub-assembly ^a 机械组件 ^a	O	O	O	O	O	O

- a. If applicable.
如果适用。

MARKING REQUIREMENTS
标注要求

Product 产品	Environmental protection use period (years) 环境保护使用期限 (年)	Logo 标志
This Exfo product 本 EXFO 产品	10	
Battery ^a 电池 ^a	5	

- a. If applicable.
如果适用。

P/N: 1065564

www.EXFO.com · info@exfo.com

CORPORATE HEADQUARTERS	400 Godin Avenue	Quebec (Quebec) G1M 2K2 CANADA Tel.: 1 418 683-0211 · Fax: 1 418 683-2170
EXFO AMERICA	3400 Waterview Parkway Suite 100	Richardson, TX 75080 USA Tel.: 1 972-761-927 · Fax: 1 972-761-9067
EXFO EUROPE	Winchester House, School Lane	Chandlers Ford, Hampshire S053 4DG ENGLAND Tel.: +44 2380 246 800 · Fax: +44 2380 246 801
EXFO ASIA-PACIFIC	100 Beach Road, #25-01/03 Shaw Tower	SINGAPORE 189702 Tel.: +65 6333 8241 · Fax: +65 6333 8242
EXFO CHINA	Beijing Global Trade Center, Tower C, Room 1207, 36 North Third Ring Road East, Dongcheng District	Beijing 100013 P. R. CHINA Tel.: +86 (10) 5825 7755 · Fax: +86 (10) 5825 7722
EXFO SERVICE ASSURANCE	270 Billerica Road	Chelmsford MA, 01824 USA Tel.: 1 978 367-5600 · Fax: 1 978 367-5700
EXFO FINLAND	Elektroniikkatie 2	FI-90590 Oulu, FINLAND Tel.: +358 (0) 403 010 300 · Fax: +358 (0) 8 564 5203
TOLL-FREE	(USA and Canada)	1 800 663-3936

© 2013 EXFO Inc. All rights reserved.
Printed in Canada (2013-11)



EXFO
EXPERTISE REACHING OUT